



**SmartGen**  
ideas for power

# APC715

## Pump Unit Controller

### USER MANUAL



**SMARTGEN (ZHENGZHOU) TECHNOLOGY CO., LTD.**



Chinese trademark

**SmartGen** English trademark

**SmartGen** — make your generator *smart*

**SmartGen Technology Co., Ltd.**

**No.28 Jinsuo Road**

**Zhengzhou**

**Henan Province**

**P. R. China**

**Tel:** 0086-371-67988888/67981888

0086-371-67991553/67992951

0086-371-67981000(overseas)

**Fax:** 0086-371-67992952

**Web:** [www.smartgen.com.cn](http://www.smartgen.com.cn)

[www.smartgen.cn](http://www.smartgen.cn)

**Email:** [sales@smartgen.cn](mailto:sales@smartgen.cn)

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to SmartGen Technology at the address above.

Any reference to trademarked product names used within this publication is owned by their respective companies.




SmartGen Technology reserves the right to change the contents of this document without prior notice.

#### Version

| Date       | Version | Note  |
|------------|---------|---|
| 2013-08-28 | 1.0     | Original release.   |
| 2014-03-06 | 1.1     | 1. Add maintenance setting description.<br>2. Add indication alarm description.<br>3. Modify some speed adjustment functions.<br>4. Add miscellaneous screen description. |
| 2019-05-21 | 1.2     | Fixed GOV terminal description and typical application diagram.   |
|            |         |   |
|            |         |   |

This manual is suitable for APC715 pump unit controller only.

Clarification of notation used within this publication.

| SYMBOL   | INSTRUCTION   |
|--|---|
|  NOTE     | Highlights an essential element of a procedure to ensure correctness.   |
|  CAUTION! | Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment. |
|  WARNING! | Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly. |

SmartGen

# CONTENTS

|       |  |    |
|-------|--|----|
| 1     | OVERVIEW .....   | 6  |
| 2     | PERFORMANCE AND CHARACTERISTICS .....  | 7  |
| 3     | SPECIFICATION .....  | 8  |
| 4     | OPERATION .....  | 9  |
| 4.1   | INDICATOR LIGHT .....  | 9  |
| 4.2   | PUSHBUTTONS.....   | 10 |
| 4.3   | LCD DISPLAY .....  | 11 |
| 4.3.1 | MAIN DISPLAY .....   | 11 |
| 4.3.2 | USER MENU AND PARAMETERS SETTING MENU .....  | 13 |
| 4.4   | AUTO START/STOP OPERATION .....  | 16 |
| 4.5   | MANUAL START/STOP OPERATION .....  | 17 |
| 4.6   | ON-LOAD CONTROL PROCESS .....  | 17 |
| 4.7   | ADJUST SPEED CONTROL.....  | 18 |
| 5     | PROTECTION.....  | 19 |
| 5.1   | WARNINGS .....   | 19 |
| 5.2   | SHUTDOWN ALARM .....   | 20 |
| 5.3   | TRIP SHUTDOWN .....  | 22 |
| 5.4   | FAULT IDLE .....   | 22 |
| 5.5   | INDICATION .....   | 22 |
| 6     | CONNECTIONS.....   | 23 |
| 7     | DEFINITION AND RANGE OF PARAMETERS .....   | 26 |
| 7.1   | PARAMETER CONTENTS AND RANGE (TABLE 1) .....   | 26 |
| 7.2   | PROGRAMMABLE OUTPUT 1-5 (TABLE 2).....   | 35 |
| 7.2.1 | Custom Period Output.....  | 39 |
| 7.2.2 | Custom Combined Output.....  | 39 |
| 7.3   | DEFINED CONTENTS OF CONFIGURABLE INPUT PORTS (ALL ACTIVE WHEN CONNECT TO GRAND (B-)) ..... | 41 |
| 7.4   | SELECTION OF SENSORS.....  | 43 |
| 7.5   | CONDITIONS OF CRANK DINSCONNECT SELECTION .....  | 43 |
| 7.6   | MAINTENANCE (FORM 6) .....   | 44 |
| 8     | PARAMETERS SETTING .....   | 45 |
| 9     | SENSOR SELECT .....  | 46 |
| 10    | TYPICAL APPLICATION.....   | 47 |
| 11    | INSTALLATION .....   | 48 |
| 12    | CONNECTIONS OF CONTROLLER WITH J1939 ENGINE .....  | 49 |
| 12.1  | CUMMINS ISB/ISBE .....   | 49 |
| 12.2  | CUMMINS QSL9 .....   | 49 |
| 12.3  | CUMMINS QSM11(IMPORT).....   | 50 |
| 12.4  | CUMMINS QSX15-CM570.....   | 50 |

---

|       |                                   |    |
|-------|-----------------------------------|----|
| 12.5  | CUMMINS GCS-MODBUS.....           | 51 |
| 12.6  | CUMMINS QSM11.....                | 51 |
| 12.7  | CUMMINS QSZ13.....                | 52 |
| 12.8  | DETROIT DIESEL DDEC III / IV..... | 52 |
| 12.9  | DEUTZ EMR2.....                   | 53 |
| 12.10 | JOHN DEERE.....                   | 53 |
| 12.11 | MTU MDEC.....                     | 53 |
| 12.12 | MTU ADEC(SMART MODULE).....       | 54 |
| 12.13 | MTU ADEC(SAM MODULE).....         | 54 |
| 12.14 | PERKINS.....                      | 55 |
| 12.15 | SCANIA.....                       | 55 |
| 12.16 | VOLVO EDC3.....                   | 55 |
| 12.17 | VOLVO EDC4.....                   | 56 |
| 12.18 | VOLVO-EMS2.....                   | 57 |
| 12.19 | YUCHAI.....                       | 57 |
| 12.20 | WEICHAI.....                      | 58 |
| 13    | USB.....                          | 58 |
| 14    | FAULT FINDING.....                | 59 |

SmartGen

## 1 OVERVIEW

**APC715 Pump Unit Controller** is designed for pump systems which controlled by engine. It allows automatic start/stop, data measurement, alarm protection as well as remote control, remote measurement and remote communication function. Utilizing the GOV (Engine Speed Governor) control function, the controller is able to stabilize the outlet/inlet pressure via GOV. CANBUS (SAE J1939) interface enables the controller to communicate with various engine which fitted with J1939 interface.

**APC715 Pump Unit Controller** fit with LCD display, optional languages interface (including English, Chinese or other languages); simultaneously the exact parameters of pump unit and engine are indicated by the LCD display on the front panel and the controller is reliable and easy to use.

**APC715 Pump Unit Controller** adopt powerful 32-bit ARM microprocessor technology with precision parameters measuring, fixed value adjustment, time setting and set value adjusting and etc. The majority of parameters can be configured from front panel and all the parameters can be set using PC (via USB port) and can be adjusted and monitored with the help of RS485 ports. It can be widely used in a number of pump control system with compact structure, simple connections and high reliability

## 2 PERFORMANCE AND CHARACTERISTICS

- 480x272 pixel, 4.3 inches coloured TFT-LCD with backlight, multilingual interface (including English, Chinese or other languages) which can be chosen at the site, making commissioning convenient for factory personnel.
- Improved LCD wear-resistance and scratch resistance due to hard screen acrylic.
- Silicon panel and pushbuttons for better operation in high/low temperature environment.
- RS485 communication port enabling remote control, remote measuring, remote communication via ModBus protocol.
- Equipped with CANBUS port and can communicate with J1939 genset. Not only can you monitoring frequently-used data (such as water temperature, oil pressure, engine speed, fuel consumption and so on) of ECU machine, but also control start, stop, raising speed and speed droop via CANBUS port.
- GOV Function; outlet pressure and inlet pressure can be adjusted via GOV function. GOV port: Relay output; Analog output (for speed control unit); CANBUS port (for engine control unit).
- The controller detects not only engine speed but also gearbox speed.
- Water pressure curve and flow curve are user-defined.
- 10 analog sensors; sensors can switch between resistor type and current type using jumper.
- More kinds of curves of temperature, oil pressure, fuel level can be used directly and users can define the sensor curves by themselves.
- Precision measure and display parameters about Engine and pump unit; e.g. engine high water temperature, low oil pressure, over speed, high water pressure, low water pressure, over flow and other kinds of fault indication and protection function..
- There are two kinds of speed adjustment ways: manually and automatically; users can adjust the speed on the panel.
- Idle control function; the genset will slow down to idle running automatically when the clutch releases.
- All output ports are relay-out;
- PLC programming function; can be applied to complex system.
- Parameter setting: parameters can be modified and stored in internal FLASH memory and cannot be lost even in case of power outage; most of them can be adjusted using front panel of the controller and all of them can be modified using PC via USB or RS485 ports.
- Multiple crank disconnect conditions (speed sensor, oil pressure) are optional;
- Widely power supply range DC(8~35)V, suitable to different starting battery voltage environment;
- Event log, real-time clock, scheduled start & stop pump unit (can be set as start pump unit once a day/week/month whether with load or not);
- Accumulative total run time A and B. Users can reset it as 0 and re-accumulative the value which make convenience to users to count the total value as their wish.
- Can control engine heater, cooler and fuel pump.
- With maintenance function. Actions can be set when maintenance time out;
- All parameters used digital adjustment, instead of conventional analog modulation with normal

- potentiometer, more reliability and stability;
- Waterproof security level IP55 due to rubber seal installed between the controller enclosure and panel fascia;
  - Metal fixing clips enable perfect performance in high temperature environment;
  - Modular design, anti-flaming ABS plastic enclosure, pluggable connection terminals and embedded installation way; compact structure with easy mounting.

### 3 SPECIFICATION

| Items                          | Contents   |
|--------------------------------|--|
| Working Voltage                | DC8. 0V to 35. 0V, Continuous Power Supply.      |
| Overall Consumption            | <4W(Standby mode: ≤2W)                           |
| Speed Sensor Voltage           | 1.0V to 24V (effective value)                    |
| Speed Sensor Frequency         | 10,000 Hz (max)                                  |
| Start Relay Output             | 16Amp DC28V power supply                         |
| Fuel Relay Output              | 16Amp DC28V power supply                         |
| Programmable Relay Output 1-6  | 7Amp DC28V power supply                          |
| Programmable Relay Output 7-10 | 7Amp AC250V power supply                         |
| Analog Sensor                  | 4 fixed sensor, 6 configurable sensor            |
| Overall Dimensions             | 266 mm x 182 mm x 45 mm                          |
| Panel Cutout                   | 214mm x 160mm                                    |
| Working Condition              | Temperature: (-25~70)°C;<br>Humidity: (20~93)%RH |
| Storage Condition              | Temperature: (-25~70)°C                          |
| Protection Level               | IP55 Gasket                                      |
| Weight                         | 0.95kg   |



## 4 OPERATION

### 4.1 INDICATOR LIGHT
















**NOTE:** Selected indicators description:




Warning indicator and Alarm indicator:

| Alarm Type     | Warning Indicator | Alarm Indicator |
|----------------|-------------------|-----------------|
| Warning        | Slow flashing     | Slow flashing   |
| Shutdown Alarm | Off               | Fast flashing   |

Running indicator: illuminated from crank successful to ETS while off during other periods.

## 4.2 PUSHBUTTONS

|   |               |  |
|---|---------------|--|
|    | Stop          | Stop running pump unit in Auto/Manual mode; Reset alarm in stop mode; Lamp test (press at least 3 seconds); During stopping process, press this button again to stop pump unit immediately.  |
|    | Start         | Start pump unit in Manual/Test mode.   |
|    | Manual Mode   | Press this key and controller enters in <b>Manual</b> mode.  |
|    | Auto Mode     | Press this key and controller enters in <b>Auto</b> mode.  |
|    | Mute          | Alarming sound off; If there is alarm, pressing the button at least 3 seconds can reset this alarm.  |
|    | Load          | Can control the clutch to switch on or off in manual mode.   |
|    | Adjust Speed  | Enter/Exit the speed adjust menu.  |
|  | Up/Increase   | 1) Screen scroll; 2) Up cursor and increase value in setting menu.   |
|  | Down/Decrease | 1) Screen scroll; 2) Down cursor and decrease value in setting menu.   |
|  | Left          | 1) Screen scroll; 2) Left move cursor in setting menu.   |
|  | Right         | 1) Screen scroll; 2) Right move cursor in setting menu.  |
|  | Set/Confirm   | <ol style="list-style-type: none"> <li>1. Enter into “help” interface;</li> <li>2. Pressing and holding for more than 3 seconds enters parameter configuration menu;</li> <li>3. In settings menu confirms the set value.</li> </ol> |
|  | Exit          | <ol style="list-style-type: none"> <li>1. Returns to the main menu;</li> <li>2. In settings menu returns to the previous menu.</li> </ol>  |


 **NOTE:** In manual mode, pressing  and  simultaneously will force generator to crank. Successful start will not be judged according to crank disconnect conditions, operator will have to crank the starter motor manually; when operator decides that the engine has fired, he/she should release the button and start relay will be deactivated, safety on delay will start.


 **WARNING:** Default password is 00318, user can change it in case of others change the

advanced parameters setting. Please clearly remember the password after changing. If you forget it, please contact Smartgen services and send all information in the controller page of “**ABOUT**” to us.

### 4.3 LCD Display

#### 4.3.1 MAIN DISPLAY


Main screen is divided into left and right separate viewing areas, use  to select a viewing area;

the selected area is marked with  in its upper left corner. Both viewing areas show pages; use

  to scroll the pages and   to scroll the screen.

★**Engine**, including as below,

Engine status, engine temperature, engine oil pressure, fuel level, Configurable Sensor 1, battery voltage, charger voltage, accumulated run time, accumulated start times.

 **NOTE:** If connected with J1939 engine via CANBUS port, this page also includes: coolant pressure, coolant level, fuel temperature, fuel pressure, inlet temperature, exhaust temperature, turbo pressure, fuel consumption, total fuel consumption and so on. (Different engine with different parameters)

★**Pump Unit:**


Outlet pressure, pump flow, pump head, config. sensor 2~6 (can be set as temperature sensor, pressure sensor or level sensor)

Formula: Pump Head = (Outlet pressure - Static Pressure)/0.0098.

Pump flow is calculated according to relation curve of outlet pressure and flow; the relation curve should be set by users according to the actual usage.

★**Alarm:**

Display all warnings, shutdown alarms, trip shutdown alarms and the corresponding information.

 **NOTE:** For ECU alarms and shutdown alarms, if the alarm information is displayed, check engine according to it, otherwise, please check the manual of generator according to SPN alarm code.

🗒 **Event log**

Records all start/stop events (shutdown alarm, trip shutdown alarm, manual/auto start or stop) and the real time when alarm occurs.

**Others**, including,


Time and Date, maintenance due time, input/output ports status.

🗒 **About**, including,

Issue time of software and hardware version, product PD number.

★**Miscellaneous**, including:

Working mode, engine status, engine temperature, engine oil pressure, fuel level, outlet pressure, config. sensor 2(inlet pressure), accumulated run time, real-time clock.

Press  in main screen can jump to **miscellaneous screen**

★**Status**, including as below,

Engine speed, battery voltage 1, engine status


| Indicator | Status                              |
|-----------|-------------------------------------|
| Green     | Normal status; No alarm             |
| Yellow    | Warning or idle speed alarm occurs. |
| Red       | Shutdown alarm occurs.              |

Example:

|                |                        |
|----------------|------------------------|
| Engine         | Pump                   |
| On load        | Outlet Pressure        |
| Manual Mode    | 1.0MPa 10Bar 145psi    |
| Normal Running | Config Sensor 2        |
| Engine Temp.   | 45°C 113°F             |
| 85°C 185°F     | Config Sensor 3        |
| Oil Pressure   | 465kPa 4.65Bar 67.4psi |
| 465kPa 4.65Bar | Config Sensor 4        |
| 67.4psi        | 100%                   |
| 1500rpm        | 27.6V                  |
| Normal Running |                        |

|                   |                      |
|-------------------|----------------------|
| Engine            | Pump                 |
| Fuel Level        | Config Sensor 5      |
| 100%              | 55°C 131°F           |
| Config Sensor 1   | Config Sensor 6      |
| 85°C 185°F        | 60°C 140°F           |
| Battery Voltage 1 | Pump Flow            |
| 27.6V             | 200m <sup>3</sup> /h |
| Battery Voltage 2 | Pump Head            |
| 27.6V             | 102m                 |
| 1500rpm           | 27.6V                |
| Emergency Stop    |                      |

### 4.3.2 USER MENU AND PARAMETERS SETTING MENU

Press and hold  for more than 3 seconds to enter into user menu;

★Parameter

After entering the correct password (factory default password is 00318), you can enter into parameter settings interface.

★Language

Selectable Chinese, English and others (default: Espanol)

★Commissioning

On load, off load or custom commissioning can be chosen. Custom commissioning can configure on load or not during commissioning, when to commissioning and select the mode after commissioning (manual mode, auto mode and stop mode).

★Clear users' accumulation

Can clear User Accumulated Run A, User Accumulated Run B, Engine Accumulated Run time and Accumulated Start times.

Parameter setting including as following,

★Timer settings

★Engine settings

★Analog sensor settings (Engine temperature, engine oil pressure, fuel level, config. 1~6, outlet pressure)

★Input port settings

★output port settings







★GOV settings

★Pump settings

★Module settings

★Scheduling and maintenance settings







Example,





|                        |                      |   |
|------------------------|----------------------|---|
| Return                 | >Start Delay         | Form1: Use   to scroll settings,  to enter settings (form2),  to exit settings menu. |
| <b>Timers</b> >        | >Stop Delay          |   |
| Engine                 | >Preheat Delay       |   |
| Temp. Sensor           | >Cranking Time       |   |
| OP Sensor              | >Crank Rest Time     |   |
| Level Sensor           | >Safety On Time      |   |
| Config Sensor 1 Config | >Start Idle Time     |   |
| Sensor 2               | >Warming Up Time     |   |
| Config Sensor 3 Config | >Cooling Time        |   |
| Sensor 4               | >Stop Idle Time      |   |
| Config Sensor 5        | >ETS Hold Time       |   |
| Return                 | > <b>Start Delay</b> | Form 2: Use   to scroll settings  |
| <b>Timers</b> >        | >Stop Delay          |   |



|                        |                  |   |
|------------------------|------------------|---|
| Engine                 | >Preheat Delay   | (form 3),  to enter settings (form 4),  to return to previous menu. (form 1). |
| Temp. Sensor           | >Cranking Time   |   |
| OP Sensor              | >Crank Rest Time |   |
| Level Sensor           | >Safety On Time  |   |
| Config Sensor 1 Config | >Start Idle Time |   |
| Sensor 2               | >Warming Up Time |   |
| Config Sensor 3 Config | >Cooling Time    |   |
| Sensor 4               | >Stop Idle Time  |   |
| Config Sensor 5        | > ETS Hold Time  |   |

|                        |                          |  |
|------------------------|--------------------------|--|
| Return                 | >Start Delay             | Form 3: Use   to scroll settings,  to enter settings (form4),  to return to previous menu. (form 1). |
| <b>Timers &gt;</b>     | >Stop Delay              |  |
|                        | >Preheat Delay           |  |
| Engine                 | <b>&gt;Cranking Time</b> |  |
| Temp. Sensor           | >Crank Rest Time         |  |
| OP Sensor              | >Safety On Time          |  |
| Level Sensor           | >Start Idle Time         |  |
| Config Sensor 1 Config | >Warming Up Time         |  |
| Sensor 2               | >Cooling Time            |  |
| Config Sensor 3 Config | >Stop Idle Time          |  |
| Sensor 4               | >ETS Hold Time           |  |
| Config Sensor 5        |                          |  |

|                          |              |   |
|--------------------------|--------------|---|
| > Start Delay            |              | Form 4: Press  to enter settings (form 5),  to return to previous menu. (form 6). |
| > Stop Delay             | <b>00008</b> |   |
| > Preheat Delay          |              |   |
| <b>&gt;Cranking Time</b> |              |   |
| >Crank Rest Time         |              |   |
| > Safety On Time         |              |   |
| > Start Idle Time        |              |   |
| > Warming Up Time        |              |   |
| > Cooling Time           |              |   |
| > Stop Idle Time         |              |   |
| > ETS Hold Time          |              |   |

|  |                     |  |
|--|---------------------|--|
| <ul style="list-style-type: none"> <li>&gt; Start Delay</li> <li>&gt; Stop Delay</li> <li>&gt; Preheat Delay</li> </ul>  | <p><b>00008</b></p> | <p>Form5: Press   to change cursor position,   are used for changing cursor value,  Confirm setting (form 4),  exit setting (form 4).</p> |
| <ul style="list-style-type: none"> <li><b>&gt; Cranking Time</b></li> <li>&gt; Crank Rest Time</li> <li>&gt; Safety On Time</li> <li>&gt; Start Idle Time</li> <li>&gt; Warming Up Time</li> <li>&gt; Cooling Time</li> <li>&gt; Stop Idle Time</li> <li>&gt; ETS Hold Time</li> </ul> |                     |  |

|   |                     |   |
|---|---------------------|---|
| <ul style="list-style-type: none"> <li>&gt; Start Delay</li> <li>&gt; Stop Delay</li> <li>&gt; Preheat Delay</li> </ul>   | <p><b>00008</b></p> | <p>Form 6:   are used for changing the setting contents.  Confirm setting (form 4),  to return to previous menu. (form 1).</p> |
| <ul style="list-style-type: none"> <li><b>&gt; Cranking Time</b></li> <li>&gt; Crank Rest Time</li> <li>&gt; Safety On Time</li> <li>&gt; Start Idle Time</li> <li>&gt; Warming Up Time</li> <li>&gt; Cooling Time</li> <li>&gt; Stop Idle Time</li> <li>&gt; ETS Hold Time</li> <li>&gt; Wait Stop Time</li> </ul> |                     |   |

 **NOTE:** Pressing  can exit setting directly during setting.




#### 4.4 AUTO START/STOP OPERATION

Auto mode is selected by pressing the  button; a LED besides the button will illuminate to confirm the operation.

##### **Automatic Start Sequence:**

1. When “Remote Start” is active, “Start Delay” timer is initiated;
2. When start delay is over, preheat relay energizes (if configured), “preheat delay XX s” information will be displayed on LCD;
3. After the above delay, the Fuel Relay is energized, and then one second later, the Start Relay is engaged. The engine is cranked for a pre-set time. If the pump unit fails to fire during this cranking attempt then the fuel relay and start relay are disengaged for the pre-set rest period; “crank rest time” begins and wait for the next crank attempt.
4. Should this start sequence continue beyond the set number of attempts, the start sequence will be terminated, the Fail to Start fault will be displayed on LCD.
5. In case of successful crank attempt, the “Safety On” timer is activated, allowing Low Oil Pressure, High Temperature, Under speed and Charge Alternator Failure inputs to stabilize without triggering the fault. As soon as this delay is over, “start idle” delay is initiated (if configured).
6. During “start idle” delay, under speed alarm is inhibited. When this delay is over, “warming up” delay is initiated (if configured).
7. After the “warming up” delay, If engine speed has reached on-load requirements, then the pump close relay will be energized; pump unit will take load; pump unit will enter into Normal Running status.



 **NOTE:** In case of “Remote Start (off Load)”, the procedure is the same, except for step NO. 7: the pump close relay will NOT be energised, generator will NOT accept load.


##### **Automatic Stop Sequence,**


- 1) When the “Remote Start” signal is deactivated while the “Remote Stop” signal is active, the Stop Delay is initiated.
- 2) Once this “stop delay” has expired, the Pump Unit Breaker will open and the “Cooling Delay” is then initiated. Should the Remote Start signal be re-activated during the cooling down period, the unit will return running status. Once the “Cooling Delay” expires, the “Stop Idle” delay is initiated.
- 3) During “Stop Idle” Delay (if configured), idle relay is energized.
- 4) “ETS Solenoid Hold” begins, ETS relay is energized while fuel relay is de-energized and complete stop is detected automatically
- 5) “Fail to Stop Delay” begins, complete stop is detected automatically.
- 6) Pump unit is placed into its “After stop time” after its complete stop. Otherwise, fail to stop alarm is initiated and the corresponding alarm information is displayed on LCD (If pump unit stopped successfully after “Failed to Stop” alarm, it will enter “After stop time” and remove alarm).
- 7) Pump unit is placed into its standby mode after its “After stop time”.




## 4.5 MANUAL START/STOP OPERATION

- Manual Start: Manual mode is selected by pressing the  button; a LED besides the button will illuminate to confirm the operation; then press  button to start the unit; can automatically detect crank successful, and unit accelerates to high-speed running automatically.


When “After Unload Idle” is enabled, the unit is idle running when crank succeed; unit accelerates to high-speed running automatically and take load after press  key by manual.

With high temperature, low oil pressure and over speed during pump unit running, controller can protect it to stop quickly (please refer to No.2~7 of Auto start operation for detail procedures).
- MANUAL STOP: Press  can stop the running pump unit. (please refer to No.2~7 of Auto stop operation for detail procedures).



 **NOTE:** In “manual mode”, users can control the pump unit on load or off load via “Load” key.

## 4.6 On-load control process


When controller is in Manual mode, manual control will be executed.


Users can control the pump unit on load or off load by pressing  key. The pump unit will unload automatically when it is stopped.

If “After Unload Idle” is selected “Disable”

Start the pump unit in manual mode and press  key during the genset is normal running, then the engine will take load; press  key again, the engine will unload and the generator is normal running.

If “After Unload Idle” is selected “Enable”:

Start the pump unit in manual mode and it enters into idle running process. The pump unit will not enter into normal running status until  key is pressed and it will take load as soon as the on-load requirements have reached.

When the pump unit is normal running with load, press  key once again will lead to the unit's offload (i.e. load relay deactivated); then the “cooling delay” will be initiated. Once this has expired, the unit will enter into idle running status.

When controller is in Auto mode, auto control will be executed.







The pump unit will take load automatically when it is normal running and the on-load requirements

have reached while unload automatically when it is stopped.

#### 4.7 ADJUST SPEED CONTROL

Users can set the outlet pressure as the rated value simply by adjusting the engine speed. The “Adjust Speed Control” was divided into auto control and manual control.

**Manual Adjust Speed:** Adjust Speed mode is selected by pressing the  button; In this interface,

users can adjust speed using navigational button: , manual adjust speed; , auto adjust speed; , manual raise speed; , manual drop speed. “, manual raise speed” and “, manual drop speed” buttons are active only when pump unit is normal running under “Manual Adjust Speed” mode.

**Auto Adjust Speed:** Under this mode, during the unit is normal running, the controller will adjust the outlet pressure/inlet pressure according to the preset to rated speed and maintain its steady automatically.

The “Auto Adjust Speed” was divided into relay adjust speed, GOV adjust speed and CAN adjust speed.

**Relay Adjust Speed:** Control the engine servo motor simply by using speed raise relay and speed drop relay.

**GOV Adjust Speed:** Control the electronic speed regulator simply by using GOV analog signal. Users should set parameters according to the actual situation as different regulators have different parameters.

**CAN Adjust Speed:** Control the ECU engine speed simply by using CAN interface. Parameters setting and speed adjustment method are same as GOV. SW1 should set as 5.0 and SW2 as 2.0 while adjusting.

## 5 PROTECTION

### 5.1 WARNINGS

Warnings are not shutdown alarms and do not affect the operation of the genset. Warning does not lead to shutdown, and when warning condition is no longer present, warning alarm will be cleared automatically. Warning types are as follows:

| No. | Type                            | Description  |
|-----|---------------------------------|--|
| 1   | Over Speed                      | When the controller detects that the engine speed has exceeded the pre-set value, it will initiate a warning alarm.                      |
| 2   | Under Speed                     | When the controller detects that the engine speed has fallen below the pre-set value, it will initiate a warning alarm.                  |
| 3   | Loss of Speed Signal            | When the controller detects that the engine speed is 0 and the action select "Warn", it will initiate a warning alarm.                   |
| 4   | Fail To Stop                    | After "fail to stop" delay, if unit is not stop completely, it will initiate a warning alarm.  |
| 5   | Charge Alt Fail                 | When the controller detects that charger voltage has fallen below the pre-set value, it will initiate a warning alarm.                   |
| 6   | Battery 1 Over Voltage          | When the controller detects that battery 1 voltage has exceeded the pre-set value, it will initiate a warning alarm.                     |
| 7   | Battery 1 Under Voltage         | When the controller detects that battery 1 voltage has fallen below the pre-set value, it will initiate a warning alarm.                 |
| 8   | Maintenance Due                 | When maintenance countdown time is 0 and the action select "Warn", it will initiate a warning alarm.                                     |
| 9   | ECU Warn                        | If an error message is received from ECU via J1939, it will initiate a warning alarm.  |
| 10  | Temperature Sensor Open Circuit | When the controller detects that the temperature sensor is open circuit and the action select "Warn", it will initiate a warning alarm.  |
| 11  | High Temperature                | When the controller detects that engine temperature has exceeded the pre-set value, it will initiate a warning alarm.                    |
| 12  | Low Temperature                 | When the controller detects that engine temperature has fallen below the pre-set value, it will initiate a warning alarm.                |
| 13  | Oil Pressure Open Circuit       | When the controller detects that the oil pressure sensor is open circuit and the action select "Warn", it will initiate a warning alarm. |
| 14  | Low Oil Pressure                | When the controller detects that the oil pressure has fallen below the pre-set value, it will initiate a warning alarm.                  |
| 15  | Level Sensor Open               | When the controller detects that the level sensor is open circuit and the action select "Warn", it will initiate a warning alarm.        |
| 16  | Low Fuel Level                  | When the controller detects that the fuel level has fallen below the pre-set value, it will initiate a warning alarm.                    |

| No. | Type                        | Description   |
|-----|-----------------------------|---|
| 17  | Flexible Sensor 1~6 Open    | When the controller detects that the sensor is open circuit and the action select "Warn", it will initiate a warning alarm.                 |
| 18  | Flexible Sensor 1~6 High    | When the controller detects the sensor value is higher than the max. set value, it will initiate a warning alarm.                           |
| 19  | Flexible Sensor 1~6 Low     | When the controller detects the sensor value is lower than the min. set value, it will initiate a warning alarm.                            |
| 20  | Digital Input 1~9 Warn      | When the action of digital input port select "Warn" and active, it will initiate a warning alarm.   |
| 21  | Battery 2 Over Voltage      | When the controller detects that battery 2 voltage has exceeded the pre-set value, it will initiate a warning alarm.                        |
| 22  | Battery 2 Under Voltage     | When the controller detects that battery 2 voltage has fallen below the pre-set value, it will initiate a warning alarm.                    |
| 23  | Outlet Pressure Sensor Open | When the controller detects that the outlet pressure sensor is open circuit and the action select "Warn", it will initiate a warning alarm. |
| 24  | Outlet Pressure Sensor High | When the controller detects the sensor value is higher than the max. set value, it will initiate a warning alarm.                           |
| 25  | Outlet Pressure Sensor Low  | When the controller detects the sensor value is lower than the min. set value, it will initiate a warning alarm.                            |
| 26  | Over Flow Warn              | When the controller detects the flow value is higher than the max. set value, it will initiate a warning alarm.                             |
| 27  | Gearbox Over speed          | When the controller detects that the gearbox speed has exceeded the pre-set value, it will initiate a warning alarm.                        |
| 28  | Gearbox Under speed         | When the controller detects that the gearbox speed has fallen below the pre-set value, it will initiate a warning alarm.                    |
| 29  | End Of The Mandate          | When the mandate time has expired and the action select "Warn", it will initiate a warning alarm.   |

## 5.2 SHUTDOWN ALARM

When controller detects shutdown alarm, it will send signal to open breaker and stop the unit. Shutdown alarm must be cleared manually and the fault removed to reset the module. Shutdown alarm types are as follows:

| NO. | Type           | Description   |
|-----|----------------|---|
| 1   | Emergency Stop | When the controller detects an emergency stop alarm signal, it will initiate a shutdown alarm.                              |
| 2   | Over Speed     | When the controller detects that the generator speed has exceeded the pre-set value, it will initiate a shutdown alarm.     |
| 3   | Under Speed    | When the controller detects that the generator speed has fallen below the pre-set value, it will initiate a shutdown alarm. |



| NO. | Type                            | Description  |
|-----|---------------------------------|--|
| 4   | Loss of Speed Signal            | When the controller detects that the engine speed is 0 and the action select "Warn", it will initiate a shutdown alarm.                          |
| 5   | Maintenance Due                 | When maintenance countdown time is 0 and the action select "Shutdown", it will initiate a shutdown alarm.  |
| 6   | ECU Shutdown                    | If shutdown alarm signal is received from ECU via J1939, it will initiate a shutdown alarm.  |
| 7   | ECU Fail                        | If the module does not detect the J1939 data, it will initiate a shutdown alarm.   |
| 8   | Temperature Sensor Open Circuit | When the controller detects that the temperature sensor is open circuit and the action select "Shutdown", it will initiate a shutdown alarm.     |
| 9   | High Temperature                | When the controller detects that engine temperature has exceeded the pre-set value, it will initiate a shutdown alarm.                           |
| 10  | Oil Pressure Open Circuit       | When the controller detects that the oil pressure sensor is open circuit and the action select "Shutdown", it will initiate a shutdown alarm.    |
| 11  | Low Oil Pressure                | When the controller detects that the oil pressure has fallen below the pre-set value, it will initiate a shutdown alarm.                         |
| 12  | Level Sensor Open Circuit       | When the controller detects that the sensor is open circuit and the action select "Shutdown", it will initiate a shutdown alarm.                 |
| 13  | Flexible Sensor 1~6 Open        | When the controller detects that the sensor is open circuit and the action select "Shutdown", it will initiate a shutdown alarm.                 |
| 16  | Flexible Sensor 1~6 High        | When the controller detects the sensor value is higher than the max. set value, it will initiate a shutdown alarm.                               |
| 17  | Flexible Sensor 1~6 Low         | When the controller detects the sensor value is lower than the min. set value, it will initiate a shutdown alarm.                                |
| 18  | Digital Input 1~9 Shutdown      | When the action of digital input port select "Shutdown" and active, it will initiate a shutdown alarm.   |
| 19  | Outlet Pressure Sensor Open     | When the controller detects that the outlet pressure sensor is open circuit and the action select "Shutdown", it will initiate a shutdown alarm. |
| 20  | Outlet Pressure Sensor High     | When the controller detects the sensor value is higher than the max. set value, it will initiate a shutdown alarm.                               |
| 21  | Outlet Pressure Sensor Low      | When the controller detects the sensor value is lower than the min. set value, it will initiate a shutdown alarm.                                |
| 22  | Over Flow Shutdown              | When the controller detects the flow value is higher than the max. set value, it will initiate a shutdown alarm.                                 |

| NO. | Type                | Description   |
|-----|---------------------|---|
| 23  | Gearbox Over speed  | When the controller detects that the gearbox speed has exceeded the pre-set value, it will initiate a shutdown alarm.     |
| 24  | Gearbox Under speed | When the controller detects that the gearbox speed has fallen below the pre-set value, it will initiate a shutdown alarm. |
| 25  | End Of The Mandate  | When the mandate time has expired and the action select "Shutdown", it will initiate a shutdown alarm.                    |

### 5.3 TRIP SHUTDOWN

On initiation of the "trip shutdown" condition the controller will de-energize the load output to remove the load from the unit. Once this has occurred, the controller will start the Cooling delay and allow the engine to cool before shutting down the engine. Trip shutdown alarm must be cleared manually and the fault removed to reset the module. Trip shutdown alarm types are as follows:

| NO. | Types             | Description   |
|-----|-------------------|---|
| 1   | Maintenance Due   | When maintenance countdown time is 0 and the action select "Trip Shutdown", it will initiate a trip shutdown alarm. |
| 2   | Digital Input 1~9 | When the action of digital input port select "Trip Shutdown" and active, it will initiate a trip shutdown alarm.    |

### 5.4 FAULT IDLE

On initiation of the trip condition the controller will de-energize the load output to remove the load from the unit. Once this has occurred the controller will start the Cooling delay and allow the engine to cool before idle running process. Fault idle alarm must be cleared by pressing "Mute" button more than 3s manually. Fault idle alarm types are as follows:

| No. | Types             | Description   |
|-----|-------------------|---|
| 1   | Digital Input 1~9 | When the action of digital input port select "Fault idle" and active, it will initiate a trip shutdown alarm. |

### 5.5 INDICATION

On initiation of the indication alarm the controller does not perform any action, and the alarm information will be displayed on Alarm page.


Indication alarm types are as follows:

| No. | Types             | Description   |
|-----|-------------------|---|
| 1   | Maintenance Due   | When maintenance countdown time is 0 and the action select "Indication", it will initiate a indication alarm. |
| 2   | Digital Input 1~9 | When the action of digital input port select "Indication" and active, it will initiate a indication alarm.    |



## 6 CONNECTIONS

APC715 controller back panel is shown below:



Description of terminal connections:

| Pin | Function           | Cable Size         | Description   |                           |
|-----|--------------------|--------------------|---|---------------------------|
| 1   | B-                 | 2.5mm <sup>2</sup> | Connected with negative of starter battery.   |                           |
| 2   | B+                 | 2.5mm <sup>2</sup> | Connected with positive of starter battery. If wire length is over 30m, better to double wires in parallel. Max. 20A fuse is recommended. |                           |
| 3   | Emergency Stop     | 2.5mm <sup>2</sup> | Connected with B+ power supply via emergency stop button.   |                           |
| 4   | Fuel Relay Output  | 1.5mm <sup>2</sup> | B+ power is supplied by terminal 3, rated 16A   |                           |
| 5   | Start Relay Output | 1.5mm <sup>2</sup> | B+ power is supplied by terminal 3, rated 16A   | Connected to starter coil |
| 6   | Aux. Output 1      | 1.5mm <sup>2</sup> | B+ power is supplied by terminal 2, rated 7A  | Details see form 2        |
| 7   | Aux. Output 2      | 1.5mm <sup>2</sup> | B+ power is supplied by terminal 2, rated 7A  |                           |
| 8   | Aux. Output 3      | 1.5mm <sup>2</sup> | B+ power is supplied by terminal 2, rated 7A  |                           |




| Pin | Function                  | Cable Size         | Description   |
|-----|---------------------------|--------------------|---|
| 9   | Aux. Output 4             | 1.5mm <sup>2</sup> | B+ power is supplied by terminal 2, rated 7A  |
| 10  | Aux. Output 5             | 1.5mm <sup>2</sup> | B+ power is supplied by terminal 2, rated 7A  |
| 11  | Aux. Output 6             | 1.5mm <sup>2</sup> | B+ power is supplied by terminal 2, rated 7A  |
| 12  | Charger(D+)               | 1.0mm <sup>2</sup> | Connected with charger starter's D+ (WL) terminals. Being hang up If there is no this terminal.                             |
| 13  | Aux. Input 1              | 1.0mm <sup>2</sup> | Ground connected is active (B-)   |
| 14  | Aux. Input 2              | 1.0mm <sup>2</sup> | Ground connected is active (B-)   |
| 15  | Aux. Input 3              | 1.0mm <sup>2</sup> | Ground connected is active (B-)   |
| 16  | Aux. Input 4              | 1.0mm <sup>2</sup> | Ground connected is active (B-)   |
| 17  | Aux. Input 5              | 1.0mm <sup>2</sup> | Ground connected is active (B-)   |
| 18  | Aux. Input 6              | 1.0mm <sup>2</sup> | Ground connected is active (B-)   |
| 19  | Aux. Input 7              | 1.0mm <sup>2</sup> | Ground connected is active (B-)   |
| 20  | Aux. Input 8              | 1.0mm <sup>2</sup> | Ground connected is active (B-)   |
| 21  | Aux. Input 9              | 1.0mm <sup>2</sup> | Ground connected is active (B-)   |
| 22  | Common GND(B-)            | 1.0mm <sup>2</sup> | (B-) has already connected innerly.   |
| 23  | Gearbox Magnetic Pickup 1 | 0.5mm <sup>2</sup> | Connected with Gearbox Speed Sensor, shielding line is recommended. (B-) has already connected with speed sensor 2 innerly. |
| 24  | Gearbox Magnetic Pickup 2 |                    |   |
| 25  | Magnetic Pickup GND       |                    | (B-) has already connected with ground innerly.   |
| 26  | Engine Magnetic Pickup 2  | 0.5mm <sup>2</sup> | Connected with Engine Speed Sensor, shielding line is recommended. (B-) has already connected with speed sensor 2 innerly.  |
| 27  | Engine Magnetic Pickup 1  |                    |   |
| 28  | Battery 2 Volt            | 1.0mm <sup>2</sup> | Connected with positive of battery 2.   |
| 29  | Aux. Output 7             | 1.5mm <sup>2</sup> | Normally close output, rated 7A   |
| 30  |                           |                    | Public points of relay  |
| 31  |                           |                    | Normally open output, rated 7A  |
| 32  | Aux. Output 8             | 1.5mm <sup>2</sup> | Normally close output, rated 7A   |
| 33  |                           |                    | Public points of relay  |
| 34  |                           |                    | Normally open output, rated 7A  |
| 35  | Aux. Output 9             | 1.5mm <sup>2</sup> | Normally close output, rated 7A   |
| 36  |                           |                    | Public points of relay  |
| 37  |                           |                    | Normally open output, rated 7A  |
| 38  | Aux. Output 10            | 1.5mm <sup>2</sup> | Normally close output, rated 7A   |
| 39  |                           |                    | Public points of relay  |

Details see form 3

Details see form 2



| Pin | Function               | Cable Size         | Description   |  |
|-----|------------------------|--------------------|---|--|
| 40  |                        |                    | Normally open output, rated 7A  |  |
| 41  | GOV B2+                | 0.5mm <sup>2</sup> | 120kΩ resistor had been connected between it and GOV B1(+) innerly.   |  |
| 42  | GOV B1+                | 0.5mm <sup>2</sup> | 2-core shielding wire is recommended, its GOV end shall be earth connected.   |  |
| 43  | GOV A-                 | 0.5mm <sup>2</sup> |   |  |
| 44  | ECU CAN L              | 0.5mm <sup>2</sup> | Impedance-120Ω shielding wire is recommended, its single-end earthed. 120Ω matched resistance has already connected internally. |  |
| 45  | ECU CAN H              | 0.5mm <sup>2</sup> |   |  |
| 46  | ECU CAN COM            | /                  |   |  |
| 47  | NC                     |                    | Not connect.  |  |
| 48  | Outlet Pressure Sensor | 1.0mm <sup>2</sup> | Connect to outlet pressure sensor   |  |
| 49  | Aux. sensor 6          | 1.0mm <sup>2</sup> | Spare sensor of pump unit   |  |
| 50  | Aux. sensor 5          | 1.0mm <sup>2</sup> |   |  |
| 51  | Sensor COM 3           | 1.0mm <sup>2</sup> | Public terminal of sensor, (B-) has already connected.  |  |
| 52  | Aux. sensor 4          | 1.0mm <sup>2</sup> | Spare sensor of pump unit   |  |
| 53  | Aux. sensor 3          | 1.0mm <sup>2</sup> |   |  |
| 54  | Aux. sensor 2          | 1.0mm <sup>2</sup> |   |  |
| 55  | Sensor COM 2           | 1.0mm <sup>2</sup> | Public terminal of sensor, (B-) has already connected.  |  |
| 56  | Aux. sensor 1          | 1.0mm <sup>2</sup> | Spare sensor of engine  |  |
| 57  | Oil pressure sensor    | 1.0mm <sup>2</sup> | Connected to oil pressure sensor  |  |
| 58  | Temperature sensor     | 1.0mm <sup>2</sup> | Connected to temperature sensor   |  |
| 59  | Fuel level sensor      | 1.0mm <sup>2</sup> | Connected to fuel level sensor  |  |
| 60  | Sensor COM 1           | 1.0mm <sup>2</sup> | Public terminal of sensor, (B-) has already connected.  |  |
| 61  | RS485                  | /                  | Impedance-120Ω shielding wire is recommended, its single-end earthed.   |  |
| 62  | RS485+                 | 0.5mm <sup>2</sup> |   |  |
| 63  | RS485-                 | 0.5mm <sup>2</sup> |   |  |

 **NOTE:** USB ports in controller rear panel are programmable parameter ports, user can directly configure controller via PC in stop mode.

## 7 DEFINITION AND RANGE OF PARAMETERS

### 7.1 PARAMETER CONTENTS AND RANGE (TABLE 1)

| No.                   | Items              | Parameter | Default | Description   |
|-----------------------|--------------------|-----------|---------|---|
| <b>Timer Setting</b>  |                    |           |         |   |
| 1                     | Start Delay        | (0-3600)s | 1       | Time from remote start signal is active to start the pump unit.   |
| 2                     | Stop Delay         | (0-3600)s | 1       | Time from remote stop signal is deactivated to stop the pump unit.  |
| 3                     | Preheat Delay      | (0-3600)s | 0       | Time of pre-powering heat plug before starter is powered up.  |
| 4                     | Cranking Time      | (3-60)s   | 8       | Time of starter power up  |
| 5                     | Crank Rest Time    | (3-60)s   | 10      | The waiting time before second power up when engine start fail.   |
| 6                     | Safety On Delay    | (0-3600)s | 10      | Alarms for low oil pressure, high temperature, under speed, under frequency/voltage, charge fail are inactive.  |
| 7                     | Start Idle Time    | (0-3600)s | 0       | Idle running time of the pump unit when starting.   |
| 8                     | Warming Up Time    | (0-3600)s | 10      | Warming time between the pump unit take load and high speed running.  |
| 9                     | Cooling Time       | (0-3600)s | 10      | Radiating time before stop the pump unit, after it unloads.   |
| 10                    | Stop Idle Time     | (0-3600)s | 0       | Idle running time when pump unit stop.  |
| 11                    | ETS Solenoid Hold  | (0-3600)s | 20      | Stop electromagnet's power on time when pump unit is stopping.  |
| 12                    | Fail to Stop Delay | (0-3600)s | 0       | Time between ending of pump unit idle delay and stopped when "ETS time" is set as 0;<br>Time between ending of ETS hold delay and stopped when "ETS Hold output time" is not 0. |
| 13                    | After Stop Time    | (0-3600)s | 0       | Time between pump unit stopped and standby.   |
| <b>Engine Setting</b> |                    |           |         |   |
| 1                     | Engine Type        | (0-39)    | 0       | Default: Conventional genset (not J1939)<br>When connected to J1939 engine, choose the corresponding type.  |
| 2                     | Flywheel Teeth     | (10-300)  | 118     | Tooth number of the engine, for judging of starter separation conditions and  |



| No. | Items                   | Parameter    | Default | Description   |
|-----|-------------------------|--------------|---------|---|
|     |                         |              |         | inspecting of engine speed. See the following Installation Instruction.   |
| 3   | Rated Speed             | (0-6000)RPM  | 1500    | Offer standard to judge over/under/loading speed.   |
| 4   | Speed on Load           | (0-1000)%    | 90%     | Setting value is percentage of rated speed. Controller detects when it is ready to load. It won't enter into normal running process when speed is lower than loading speed. |
| 5   | Loss of Speed Signal    | (0-3600)s    | 5       | Time from detecting speed is 0 to confirm the action.   |
| 6   | Loss of Speed Action    | (0-1)        | 0       | 0:Warn; 1:Shutdown  |
| 7   | Over Speed Shutdown     | (0-1000)%    | 114%    | Setting value is percentage of rated speed and delay value can be set.  |
| 8   | Under Speed Shutdown    | (0-1000)%    | 80%     |   |
| 9   | Over Speed Warn         | (0-1000)%    | 110%    | Setting value is percentage of rated speed. Delay value and return value can be set.  |
| 10  | Under Speed Warn        | (0-1000)%    | 86%     |   |
| 11  | Battery 1 Rated Voltage | (0-60.0)V    | 24.0    | Standard for detecting over/under voltage of battery.   |
| 12  | Battery 1 Over Volts    | (0-1000)%    | 120%    | Setting value is percentage of rated voltage of battery. Delay value & return value can be set.   |
| 13  | Battery 1 Under Volts   | (0-1000)%    | 85%     |   |
| 14  | Battery 2 Rated Voltage | (0-60.0)V    | 24.0    | Standard for detecting over/under voltage of battery.   |
| 15  | Battery 2 Over Volts    | (0-1000)%    | 120%    | Setting value is percentage of rated voltage of battery. Delay value & return value can be set.   |
| 16  | Battery 2 Under Volts   | (0-1000)%    | 85%     |   |
| 17  | Charge Alt Fail         | (0-60.0)V    | 8.0     | In normal running, when charger D+(WL) voltage under this value, charge failure alarms.   |
| 18  | Start Attempts          | (1-10) times | 3       | Max. Crank times of crank attempts. When reach this number, controller will send start failure signal.  |
| 19  | Crank Disconnect        | (0-2)        | 2       | See form 5.<br>There are 3 conditions of disconnecting  |



| No.                                       | Items                   | Parameter   | Default | Description   |
|---|-------------------------|-------------|---------|---|
|   |                         |             |         | starter with engine. Each condition can be used alone and simultaneously to separating the start motor and genset as soon as possible.  |
| 20  | Disconnect Engine Speed | (0-1000)%   | 24%     | Setting value is percentage of rated speed. When engine speed is higher than the set value, starter will be disconnected. See the following Installation Instruction.                             |
| 21  | Disconnect Oil Pressure | (0-1000)kPa | 200     | When generator oil pressure is higher than the set value, starter will be disconnected. See the following Installation Instruction.   |
| 22  | After Unload Idle       | (0-1)       | 0       | 0: Disable ; 1: Enable Active when system is in manual mode. After start the unit, it is enter into idle running when the unit is not on-load.  |
| 23  | Engine Idle Set         | (0-100)%    | 60      | Setting value is percentage of rated speed. Stabilize the engine speed on the set value if idle running is needed.  |
| <b>Module Setting</b>                     |                         |             |         |   |
| 1   | Power on Mode           | (0-2)       | 0       | 0: Stop mode 1: Manual mode 2: Auto mode  |
| 2   | Module Address          | (1-254)     | 1       | Controller's address during remote sensing.   |
| 3   | Stop Bits               | (0-1)       | 0       | 0: 2 stop bits; 1: 1 stop bit   |
| 4   | Language                | (0-2)       | 0       | 0: Simplified Chinese 1: English 2: Others  |
| 5   | Password                | (0-65535)   | 00318   | For entering advanced parameters setting.   |
| 6   | Time and Date           |             |         | User set  |
| <b>Scheduling And Maintenance Setting</b> |                         |             |         |   |
| 1   | Scheduled Run           | (0-1)       | 0       | 0: Disable; 1: Enable   |
| 2   | Scheduled Not Run       | (0-1)       | 0       | 0: Disable; 1: Enable   |
| 3   | Maintenance 1           | (0-1)       | 0       | 0: Disable; 1: Enable<br>Users can set maintenance time, maintenance due action, prealarm A, prealarm B, timer mode and reset maintenance alarm. If maintenance due alarm occurs, users can reset |
| 4   | Maintenance 2           | (0-1)       | 0       |   |
| 5   | Maintenance 3           | (0-1)       | 0       |   |
| 6   | Maintenance 4           | (0-1)       | 0       |   |
| 7   | Maintenance 5           | (0-1)       | 0       |   |



| No.                           | Items               | Parameter   | Default | Description  |
|-------------------------------|---------------------|-------------|---------|--|
|                               |                     |             |         | maintenance alarm to remove it.  |
| <b>Analog Sensors Setting</b> |                     |             |         |  |
| Temperature Sensor            |                     |             |         |  |
| 1                             | Curve Type          | (0-15)      | 7       | SGX. See form 5.   |
| 2                             | Open Circuit Action | (0-2)       | 0       | 0: Warn; 1: Shutdown; 2: No action   |
| 3                             | High Temp. Shutdown | (0~300)°C   | 98      | Shutdown when external sensor temperature is higher than this value. Detecting only after safety delay is over. The delay value can be set.              |
| 4                             | High Temp. Warn     | (0~300)°C   | 95      | Warn when external sensor temperature is higher than this value. Detecting only after safety delay is over. The delay value and return value can be set. |
| 5                             | Low Temp. Warn      | (0-1)       | 0       | 0: Disable; 1: Enable  |
| 6                             | Custom Curve        |             |         | Users should set the corresponding curve when select resistor curve type or current curve type.  |
| Oil Pressure Sensor           |                     |             |         |  |
| 1                             | Curve Type          | (0-15)      | 7       | SGX. See form 5.   |
| 2                             | Open Circuit Action | (0-2)       | 0       | 0: Warn; 1: Shutdown; 2: No action   |
| 3                             | Low OP Shutdown     | (0-1000)kPa | 103     | Shutdown when external oil pressure is lower than this value. Detecting only after safety delay is over. The delay value can be set.                     |
| 4                             | Low OP Warn         | (0-1000)kPa | 124     | Warn when external oil pressure is higher than this value. Detecting only after safety delay is over. The delay value and return value can be set.       |
| 5                             | Custom Curve        |             |         | Users should set the corresponding curve when select resistor curve type or current curve type.  |
| Liquid Level Sensor           |                     |             |         |  |
| 1                             | Curve Type          | (0-15)      | 4       | SGH. See form 5.   |
| 2                             | Open Circuit Action | (0-2)       | 0       | 0:Warn; 1:Shutdown; 2:No action  |
| 3                             | Low Level Warn      | (0-1000)%   | 10      | Warn when external level is lower than this value. It is detecting all the time. The delay value and return value can be set.                            |



| No.                           | Items                   | Parameter | Default | Description  |
|-------------------------------|-------------------------|-----------|---------|--|
| 4                             | Custom Curve            |           |         | Users should set the corresponding curve when select resistor curve type or current curve type.                        |
| <b>Flexible Sensor 1~6</b>    |                         |           |         |  |
| 1                             | Flexible Sensor Setting | (0-1)     | 0       | 0: Disable ; 1: Enable (can be set as temperature/oil pressure/liquid level sensor)                                    |
| 2                             | Curve Type              |           |         | Depends on sensor type.  |
| 3                             | Open Circuit Action     | (0-2)     | 0       | 0:Warn; 1:Shutdown; 2:No action  |
| 4                             | High Shutdown           | (0-9000)  | 100     | Shutdown when external sensor value is higher than this value. The delay value and "warn enable" can be set.           |
| 5                             | Low Shutdown            | (0-9000)  | 10      | Shutdown when external sensor value is lower than this value. The delay value and "warn enable" can be set.            |
| 6                             | High Warn               | (0-9000)  | 90      | Warn when external sensor value is higher than this value. The delay value, "warn enable" and return value can be set. |
| 7                             | Low Warn                | (0-9000)  | 20      | Warn when external sensor value is lower than this value. The delay value, "warn enable" and return value can be set.  |
| 8                             | Custom Curve            |           |         | Users should set the corresponding curve when select resistor curve type or current curve type.                        |
| <b>Outlet Pressure Sensor</b> |                         |           |         |  |
| 1                             | Curve Type              | (0-15)    | 2       |  |
| 2                             | Open Circuit Action     | (0-2)     | 1       | 0:Warn; 1:Shutdown; 2:No action  |
| 3                             | High Shutdown           | (0-9000)% | 120     | Shutdown when external sensor value is higher than this value. The delay value and "warn enable" can be set.           |
| 4                             | Low Shutdown            | (0-9000)% | 10      | Shutdown when external sensor value is lower than this value. The delay value and "warn enable" can be set.            |
| 5                             | High Warn               | (0-9000)% | 110     | Warn when external sensor value is higher than this value. The delay value, "warn enable" and return value can be set. |
| 6                             | Low Warn                | (0-9000)% | 20      | Warn when external sensor value is lower   |





| No.                         | Items                 | Parameter                  | Default | Description   |
|-----------------------------|-----------------------|----------------------------|---------|---|
|                             |                       |                            |         | than this value. The delay value, "warn enable" and return value can be set.  |
| 7                           | Custom Curve          |                            |         | Users should set the corresponding curve when select resistor curve type or current curve type.   |
| 8                           | Rated Outlet Pressure | (0-9000)kPa                | 1000    | Set the outlet port's rated working pressure of pump unit.  |
| 9                           | Static Pressure       | (0-9000)kPa                | 0       | Set the outlet port's static pressure of pump unit.   |
| 10                          | Flow Function         | (0-1)                      | 0       | 0: Disable; 1: Enable   |
| 11                          | Rated Flow            | (0-10000)m <sup>3</sup> /h | 1000    | Pump unit's rated working pressure.   |
| 12                          | Over Flow Warn        | (0-1000)%                  | 110     | During normal running process, it will initiated a warning alarm signal when flow value has exceed the set value. The delay value, "warn enable" and return value can be set. |
| 13                          | Over Flow Shut        | (0-1000)%                  | 120     | During normal running process, it will initiate a shutdown alarm signal when flow value has exceeded the set value. The "warn enable" and delay value can be set.             |
| 14                          | Flow Curve            |                            |         | Different outlet pressures correspond to different flow value.  |
| <b>Flexible Input Ports</b> |                       |                            |         |   |
| Flexible Input Port 1       |                       |                            |         |   |
| 1                           | Contents Setting      | (0-53)                     | 28      | Remote start (on load). See form 3.   |
| 2                           | Active Type           | (0-1)                      | 0       | 0: Closed to active 1: Open to active   |
| Flexible Input Port 2       |                       |                            |         |   |
| 1                           | Contents Setting      | (0-53)                     | 26      | High temperature shutdown. See form 3.  |
| 2                           | Active Type           | (0-1)                      | 0       | 0: Closed to active 1: Open to active   |
| Flexible Input Port 3       |                       |                            |         |   |
| 1                           | Contents Setting      | (0-53)                     | 27      | Low oil pressure shutdown. See form 3.  |
| 2                           | Active Type           | (0-1)                      | 0       | 0: Closed to active 1: Open to active   |
| Flexible Input Port 4       |                       |                            |         |   |
| 1                           | Contents Setting      | (0-53)                     | 0       | User defined. See form 3.   |
| 2                           | Active Type           | (0-1)                      | 0       | 0: Closed to active 1: Open to active   |
| 3                           | Arming                | (0-3)                      | 2       | 0: From safety on 1: From starting<br>2: Always 3:Never   |



| No.                            | Items            | Parameter | Default | Description  |
|--------------------------------|------------------|-----------|---------|--|
| 4                              | Active Actions   | (0-4)     | 0       | 0: Warn; 1: Shutdown; 2: Trip Shutdown 3: Fault Idle 4: Indication |
| 5                              | Active Delay     | (0-20.0)s | 2.0     | Time from detecting active to confirm.                             |
| 6                              | Description      |           |         | User defined.  |
| <b>Flexible Input Port 5</b>   |                  |           |         |  |
| 1                              | Contents Setting | (0-53)    | 0       | User defined. See form 3.  |
| 2                              | Active Type      | (0-1)     | 0       | 0: Closed to active 1: Open to active                              |
| 3                              | Arming           | (0-3)     | 2       | 0: From safety on 1: From starting<br>2: Always 3:Never            |
| 4                              | Active Actions   | (0-4)     | 0       | 0: Warn; 1: Shutdown; 2: Trip Shutdown 3: Fault Idle 4: Indication |
| 5                              | Active Delay     | (0-20.0)s | 2.0     | Time from detecting active to confirm.                             |
| 6                              | Description      |           |         | User defined.  |
| <b>Flexible Input Port 6</b>   |                  |           |         |  |
| 1                              | Contents Setting | (0-53)    | 0       | User defined. See form 3.  |
| 2                              | Active Type      | (0-1)     | 0       | 0: Closed to active 1: Open to active                              |
| 3                              | Arming           | (0-3)     | 2       | 0: From safety on 1: From starting<br>2: Always 3:Never            |
| 4                              | Active Actions   | (0-4)     | 1       | 0: Warn; 1: Shutdown; 2: Trip Shutdown 3: Fault Idle 4: Indication |
| 5                              | Active Delay     | (0-20.0)s | 2.0     | Time from detecting active to confirm.                             |
| 6                              | Description      |           |         | User defined.  |
| <b>Flexible Input Port 7</b>   |                  |           |         |  |
| 1                              | Contents Setting | (0-53)    | 5       | Lamp Test. See form 3.   |
| 2                              | Active Type      | (0-1)     | 0       | 0: Closed to active 1: Open to active                              |
| <b>Flexible Input Port 8~9</b> |                  |           |         |  |
| 1                              | Contents Setting | (0-53)    | 0       | User defined. See form 3.  |
| 2                              | Active Type      | (0-1)     | 0       | 0: Closed to active 1: Open to active                              |
| 3                              | Arming           | (0-3)     | 0       | 0: From safety on 1: From starting<br>2: Always 3:Never            |
| 4                              | Active Actions   | (0-4)     | 0       | 0: Warn; 1: Shutdown; 2: Trip Shutdown 3: Fault Idle 4: Indication |
| 5                              | Active Delay     | (0-20.0)s | 2.0     | Time from detecting active to confirm.                             |
| 6                              | Description      |           |         | User defined.  |
| <b>Flexible Output Ports</b>   |                  |           |         |  |
| <b>Flexible Output Port 1</b>  |                  |           |         |  |
| 1                              | Contents         | (0-239)   | 1       | User defined period output (default output                         |





| No.                       | Items                        | Parameter | Default | Description   |
|---------------------------|------------------------------|-----------|---------|---|
|                           | Setting                      |           |         | is in preheating) See form 4.                           |
| 2                         | Active Type                  | (0-1)     | 0       | 0:Normally open; 1:Normally close                       |
| Flexible Output Port 2    |                              |           |         |   |
| 1                         | Contents Setting             | (0-239)   | 35      | Idle speed control. See form 4.                         |
| 2                         | Active Type                  | (0-1)     | 0       | 0:Normally open; 1:Normally close                       |
| Flexible Output Port 3    |                              |           |         |   |
| 1                         | Contents Setting             | (0-239)   | 29      | On-load control. See form 4.                            |
| 2                         | Active Type                  | (0-1)     | 0       | 0:Normally open; 1:Normally close                       |
| Flexible Output Port 4    |                              |           |         |   |
| 1                         | Contents Setting             | (0-239)   | 31      | Reserved. See form 4.                                   |
| 2                         | Active Type                  | (0-1)     | 0       | 0:Normally open; 1:Normally close                       |
| Flexible Output Port 5    |                              |           |         |   |
| 1                         | Contents Setting             | (0-239)   | 38      | ETS solenoid hold. See form 4.                          |
| 2                         | Active Type                  | (0-1)     | 0       | 0:Normally open; 1:Normally close                       |
| Flexible Output Port 6    |                              |           |         |   |
| 1                         | Contents Setting             | (0-239)   | 48      | Common alarm. See form 4.                               |
| 2                         | Active Type                  | (0-1)     | 0       | 0:Normally open; 1:Normally close                       |
| Flexible Output Port 7~10 |                              |           |         |   |
| 1                         | Contents Setting             | (0-239)   | 0       | Not used. See form 4.                                   |
| 2                         | Active Type                  | (0-1)     | 0       | 0:Normally open; 1:Normally close                       |
| GOV Setting               |                              |           |         |   |
| 1                         | Adjust Speed Type            | (0-2)     | 2       | 0: Not Used; 1: Relay Adjust Speed; 2: GOV Adjust Speed |
| 2                         | GOV Output Reverse           | (0-1)     | 0       | 0: Disable; 1: Enable.                                  |
| 3                         | GOV Center Voltage SW1       | (0-10.0)  | 0       | Default central voltage: 0V                             |
| 4                         | GOV Voltage Range SW2        | (0-10.0)  | 2.0     | Default volt. range: (-2.5~+2.5)V                       |
| 5                         | GOV Gain                     | (0-100)   | 20      | GOV gain control  |
| 6                         | GOV Stability                | (0-100)   | 20      | GOV stability control                                   |
| 7                         | Relay Adjust Speed Dead Band | (0-10.0)% | 1.0     | GOV relay control                                       |
| 8                         | GOV Relay                    | (0-100)%  | 10      |   |



| No.                      | Items                    | Parameter    | Default | Description   |
|--------------------------|--------------------------|--------------|---------|---|
|                          | Gain                     |              |         |   |
| 9                        | GOV Relay Stability      | (0.05-1.60)s | 0.10    |   |
| 10                       | GOV Relay Response       | (0.25-4.00)  | 0.5     |   |
| 11                       | Adjust Speed Object      | (0-1)        | 0       | 0: Outlet Pressure, 1: Inlet Pressure<br>Configurable sensor 2 is regarded as inlet pressure sensor if the object is set as "Inlet Pressure". |
| 12                       | Inlet Pressure Stability | (0-2000)kPa  | 10      | Stabilize the inlet pressure on the set value if the object is set as "Inlet Pressure".   |
| <b>Pump Unit Setting</b> |                          |              |         |   |
| 1                        | Speed Enabled            | (0-1)        | 0       | 0: Disable; 1: Enable.  |
| 2                        | Flywheel Teeth           | (1-300)      | 118     | Tooth number of the engine.   |
| 3                        | Rated Speed              | (0-6000)RPM  | 500     | Offer standard to judge over/under speed.   |
| 4                        | Over Speed Shut          | (0-1000)%    | 114%    | Setting value is percentage of rated speed and delay value can be set.  |
| 5                        | Under Speed Shut         | (0-1000)%    | 80%     |   |
| 6                        | Over Speed Warn          | (0-1000)%    | 110%    | Setting value is percentage of rated speed. Delay value and return value can be set.  |
| 7                        | Under Speed Warn         | (0-1000)%    | 86%     |   |

**7.2 PROGRAMMABLE OUTPUT 1-5 (TABLE 2)**

| No. | Type              | Description  |
|-----|-------------------|--|
| 0   | Not Used          |  |
| 1   | Custom Period 1   | Details of function description please see the following.  |
| 2   | Custom Period 2   |  |
| 3   | Custom Period 3   |  |
| 4   | Custom Period 4   |  |
| 5   | Custom Period 5   |  |
| 6   | Custom Period 6   |  |
| 7   | Custom Combined 1 |  |
| 8   | Custom Combined 2 |  |
| 9   | Custom Combined 3 |  |
| 10  | Custom Combined 4 |  |
| 11  | Custom Combined 5 |  |
| 12  | Custom Combined 6 |  |
| 13  | Reserved          |  |
| 14  | Reserved          |  |
| 15  | Reserved          |  |
| 16  | Start Relay B     | If "Start Relay B" is configured, start relay and start relay B will output alternately in multi-startup process; Are used to control double power supply ATS. |
| 17  | Air Flap          | Action when over speed shutdown and emergence stop. It can close the air inflow to stop the engine as soon as possible.  |
| 18  | Audible Alarm     | Action when warning or shutdown occurs. Can be connected annunciator externally. When "alarm mute" input port is active, the alarm will be prohibit.           |
| 19  | Louver Control    | Action in genset starting and disconnect when genset stopped completely.   |
| 20  | Fuel Pump Control | It is controlled by fuel pump of level sensor's limited threshold.   |
| 21  | Heater Control    | It is controlled by heating of temperature sensor's limited threshold.   |
| 22  | Cooler Control    | It is controlled by cooler of temperature sensor's limited threshold.  |
| 23  | Oil Pre-supply    | Actions in period of cranking to safety run.   |
| 24  | Reserved          |  |
| 25  | Pre-Lubricate     | Actions in period of pre-heating to safety run.  |
| 26  | Remote PC Output  | This port is controlled by RS485   |

| No. | Type                | Description  |
|-----|---------------------|--|
|     |                     | communication (PC).  |
| 27  | Reserved            |  |
| 28  | Reserved            |  |
| 29  | On-load Output      | Control generator to take load or off load.  |
| 30  | Reserved            |  |
| 31  | Reserved            |  |
| 32  | Reserved            |  |
| 33  | Crank Relay         | Action when genset is starting and disconnect when crank successful.   |
| 34  | Fuel Relay          | Action when genset is starting and disconnect when stop is completed.  |
| 35  | Idle Control        | Used for engine which has idles. Close before starting and open in warming up delay; Close during stopping idle process and open when stop is completed. |
| 36  | Raise Speed         | Action in warming up delay and be controlled by GOV in normal running process.   |
| 37  | Drop Speed          | Action between the period from “stop idle” to “failed to stop” and be controlled by GOV in normal running process.                                       |
| 38  | ETS Control         | Used for engines with ETS electromagnet. Close when stop idle is over and open when pre-set “ETS delay” is over.   |
| 39  | Pulse Drop speed    | Active 0.1s when controller enter into stop idle, used for control part of ECU dropping to idle speed (temporary reserved).                              |
| 40  | ECU Stop            | Suitable for engines which fitted with ECU; used for control ECU stop.   |
| 41  | ECU Power Supply    | Suitable for engines which fitted with ECU; used for control ECU power supply.   |
| 42  | Pulse raise speed   | Active 0.1s when controller enter into warming up delay; used for control part of ECU raising to normal speed (temporary reserved).                      |
| 43  | Crank Success       | Close when detects a successful start signal.  |
| 44  | Reserved            |  |
| 45  | Reserved            |  |
| 46  | Reserved            |  |
| 47  | Start Battery Cycle | During cranking process, start battery will be switchover circularly if multiple crank is needed.  |
| 48  | Common Alarm        | Action when pump unit common warning,  |

| No.   | Type                    | Description                                       |
|-------|-------------------------|---|
|       |                         | common shutdown alarm.                            |
| 49    | Common Trip             | Action when common trip alarm.                    |
| 50    | Common Shutdown         | Action when common shutdown alarm.                |
| 51    | Common Fault Idle Alarm | Action when fault idle alarm.                     |
| 52    | Common Warn Alarm       | Action when common warning alarm.                 |
| 53    | Reserved                |   |
| 54    | Battery 1 High Volts    | Action when battery 1 over voltage warning alarm. |
| 55    | Battery 1 Low Volts     | Action when battery 1 low voltage warning alarm.  |
| 56    | Charge Alt Fail         | Action when charge failure warning alarms.        |
| 57    | Reserved                |   |
| 58    | Reserved                |   |
| 59    | Reserved                |   |
| 60    | ECU Warn                | Indicate ECU sends a warning signal.              |
| 61    | ECU Shutdown            | Indicate ECU sends a shutdown signal.             |
| 62    | ECU COM Fail            | Indicate controller cannot communicate with ECU.  |
| 63    | Reserved                |   |
| 64    | Reserved                |   |
| 65    | Reserved                |   |
| 66    | Reserved                |   |
| 67    | Reserved                |   |
| 68    | Reserved                |   |
| 69    | Aux Input 1 Active      | Action when input port 1 is active.               |
| 70    | Aux Input 2 Active      | Action when input port 2 is active.               |
| 71    | Aux Input 3 Active      | Action when input port 3 is active.               |
| 72    | Aux Input 4 Active      | Action when input port 4 is active.               |
| 73    | Aux Input 5 Active      | Action when input port 5 is active.               |
| 74    | Aux Input 6 Active      | Action when input port 6 is active.               |
| 75    | Aux Input 7 Active      | Action when input port 7 is active.               |
| 76    | Aux Input 8 Active      | Action when input port 8 is active.               |
| 77    | Aux Input 9 Active      | Action when input port 9 is active.               |
| 78~96 | Reserved                |   |
| 97    | Battery 2 High Volts    | Action when battery 2 over voltage warning alarm. |
| 98    | Battery 2 Low Volts     | Action when battery 2 low voltage warning alarm.  |
| 99    | Emergency Stop          | Action when emergency stop alarm.                 |
| 100   | Failed To Start         | Action when failed start alarm.                   |
| 101   | Failed To Stop          | Action when failed stop alarm.                    |

| No.     | Type                 | Description                                      |
|---------|----------------------|--|
| 102     | Under Speed Warn     | Action when under speed alarm.                   |
| 103     | Under Speed Shutdown | Action when under speed shuts down.              |
| 104     | Over Speed Warn      | Action when over speed warning.                  |
| 105     | Over Speed Shutdown  | Action when over speed shutdown alarm.           |
| 106~138 | Reserved             |  |
| 139     | High Temp Warn       | Action when high temperature warning.            |
| 140     | Low Temp Warn        | Action when low temperature warning.             |
| 141     | High Temp Shutdown   | Action when hi-temperature Shutdown alarm.       |
| 142     | Reserved             |  |
| 143     | Low OP Warn          | Action when low oil pressure warning.            |
| 144     | Low OP Shutdown      | Action when low oil pressure shutdown.           |
| 145     | OP Sensor Open       | Action when oil pressure sensor is open circuit. |
| 146     | Reserved             |  |
| 147     | Low Level Warn       | Action when low oil level warning.               |
| 148     | Over Flow Shutdown   | Action when low oil pressure shutdown.           |
| 149     | Over Flow Warn       | Action when low oil pressure warning.            |
| 150     | Config 1 High Warn   |  |
| 151     | Config 1 Low Warn    |  |
| 152     | Config 1 High Shut   |  |
| 153     | Config 1 Low Shut    |  |
| 154     | Config 2 High Warn   |  |
| 155     | Config 2 Low Warn    |  |
| 156     | Config 2 High Shut   |  |
| 157     | Config 2 Low Shut    |  |
| 158     | Config 3 High Warn   |  |
| 159     | Config 3 Low Warn    |  |
| 160     | Config 3 High Shut   |  |
| 161     | Config 3 Low Shut    |  |
| 162     | Config 4 High Warn   |  |
| 163     | Config 4 Low Warn    |  |
| 164     | Config 4 High Shut   |  |
| 165     | Config 4 Low Shut    |  |
| 166     | Config 5 High Warn   |  |
| 167     | Config 5 Low Warn    |  |
| 168     | Config 5 High Shut   |  |
| 169     | Config 5 Low Shut    |  |
| 170     | Config 6 High Warn   |  |
| 171     | Config 6 Low Warn    |  |
| 172     | Config 6 High Shut   |  |

| No.     | Type              | Description                     |
|---------|-------------------|---------------------------------|
| 173     | Config 6 Low Shut |                                 |
| 174     | Outlet High Warn  |                                 |
| 175     | Outlet Low Warn   |                                 |
| 176     | Outlet High Shut  |                                 |
| 177     | Outlet Low Shut   |                                 |
| 178~229 | Reserved          |                                 |
| 230     | Stop Mode         | Action in stop mode.            |
| 231     | Manual Mode       | Action in Manual mode.          |
| 232     | Reserved          |                                 |
| 233     | Auto Mode         | Action in Auto mode.            |
| 234     | Loading Status    | Indicate the system is on-load. |
| 235~239 | Reserved          |                                 |

### 7.1.1 Custom Period Output

Defined Period output is composed by 2 parts, period output S1 and condition output S2.



While S1 and S2 are **TRUE** synchronously, OUTPUT;

While S1 or S2 is **FALSE**, NOT OUTPUT.

Period output S1, can set pump unit's one or more period output freely, can set the delayed time and output time after enter into period.

Condition output S2; can set as any conditions in output ports.

**NOTE:** when delay time and output time both are 0 in period output S1, it is **TRUE** in this period.

Example,

Output period: start

Delay output time: 2s

Output time: 3s

Condition output contents: output port 1 is active


Close when condition output active/inactive: close when active (disconnect when inactive);

Output port 1 active, after enter "starts time" and delay 2s, this defined period output is outputting, after 3s, stop outputting;

Output port 1 inactive, defined output period is not outputting.

### 7.1.2 Custom Combined Output

Defined combination output is composed by 3 parts, condition output S1 or S2 and condition output S3.



S1 or S2 is **TRUE**, while S3 is **TRUE**, Defined combination output is outputting;

S1 and S2 are **FALSE**, or S3 is **FALSE**, Defined combination output is not outputting.



**NOTE:** S1, S2, S3 can be set as any contents except for “defined combination output” in the output setting.

**NOTE:** 3 parts of defined combination output (S1, S2, S3) couldn't include or recursively include themselves.

Example,

Contents of probably condition output S1: output port 1 is active;

Close when probably condition output S1 is active /inactive: close when active (disconnect when inactive);

Contents of probably condition output S2, output port 2 is active;

Close when probably condition output S2 is active /inactive: close when active (disconnect when inactive);

Contents of probably condition output S3: output port 3 is active;



Close when probably condition output S3 is active /inactive: close when active (disconnect when inactive);

When input port 1 active or input port 2 active, if input port 3 is active, Defined combination output is outputting; If input port 3 inactive, Defined combination output is not outputting;

When input port 1 inactive and input port 2 inactive, whatever input port 3 is active or not, Defined combination output is not outputting.



### 7.3 DEFINED CONTENTS OF CONFIGURABLE INPUT PORTS (ALL ACTIVE WHEN CONNECT TO GRAND (B-))

| No. | Type               | Description  |
|-----|--------------------|--|
| 0   | Users Configured   | Including following functions,<br>Indication: indicate only, not warning or shutdown.<br>Warning: warn only, not shutdown.<br>Shutdown: alarm and shutdown immediately<br>Never: input inactive.<br>Always: input is active all the time.<br>From crank: detecting as soon as start.<br>From safety on: detecting after safety on run delay. |
| 1   | Reserved           |  |
| 2   | Alarm Mute         | Can prohibit "Audible Alarm" output when input is active.  |
| 3   | Reset Alarm        | Can reset shutdown alarm when input is active.   |
| 4   | Reserved           |  |
| 5   | Lamp Test          | All LED indicators are illuminating when input is active.  |
| 6   | Panel Lock         | All buttons in panel is inactive except  and there is  in the left of first row in LCD when input is active.  |
| 7   | Crank Success      | Means that the engine is start successfully when the input is active. Crank success condition judge are disabled if the "Crank Success" is configured.   |
| 8   | Idle Control Mode  | Under speed protection is inactive.  |
| 9   | Inhibit Auto Stop  | In <b>Auto</b> mode, during pump unit normal running, when input is active, inhibit pump unit shutdown automatically.  |
| 10  | Inhibit Auto Start | In <b>Auto</b> mode, inhibit pump unit start automatically when input is active.   |
| 11  | Inhibit Scheduled  | In <b>Auto</b> mode, inhibit pump unit scheduled run when input is active.   |
| 12  | Reserved           |  |
| 13  | Loading Status     | Connect to Aux. Points of clutch.  |
| 14  | Load Inhibit       | Prohibit pump unit onload when input is active.  |
| 15  | Reserved           |  |
| 16  | Reserved           |  |
| 17  | Reserved           |  |
| 18  | Reserved           |  |
| 19  | Reserved           |  |
| 20  | Reserved           |  |
| 21  | Inhibit Alarm Stop | All shutdown alarms are prohibited except emergence stop.(Means battle mode)   |

| No.   | Type                    | Description  |
|-------|-------------------------|--|
| 22    | Aux Instrument Mode     | All outputs are prohibited in this mode.   |
| 23    | Reserved                |  |
| 24    | Reset Maintenance       | Controller will reset maintenance 1 time and date as default when input is active.   |
| 25    | Reserved                |  |
| 26    | Aux. High Temp          | Connect to sensor digital input.   |
| 27    | Aux. Low OP             | Connect to sensor digital input.   |
| 28    | Remote Start (On Load)  | In <b>Auto</b> mode, when the input is active, pump unit can be started automatically and take load after pump unit normal running.          |
| 29    | Remote Start (Off Load) | In <b>Auto</b> mode, when the input is active, pump unit can be started automatically and NOT take load after pump unit normal running.      |
| 30    | Aux. Manual Start       | In <b>Manual</b> mode, when the input is active, pump unit will start automatically; when input inactive, pump unit will stop automatically. |
| 31    | Reserved                |  |
| 32    | Remote Stop             | In <b>Auto</b> mode, when the input is active as well as remote start signal is inactive, pump unit can be stopped automatically.            |
| 33    | Simulate Stop key       | An external button (not self-locking) can be connected and pressed as simulate panel.  |
| 34    | Simulate Manual key     |  |
| 35    | Reserved                |  |
| 36    | Simulate Auto key       | An external button (not self-locking) can be connected and pressed as simulate panel.  |
| 37    | Simulate Start key      |  |
| 38    | Simulate Load key       |  |
| 39-51 | Reserved                |  |
| 52    | Speed Raise Input       | An external button (not self-locking) can be connected and control GOV manually.   |
| 53    | Speed Drop Input        |  |

## 7.4 SELECTION OF SENSORS

| No. |                    | Description   | Remark  |
|-----|--------------------|---|---|
| 1   | Temperature Sensor | 0 Not used<br>1 Custom Res Curve<br>2 Custom 4-20mA curve<br>3 VDO<br>4 CURTIS<br>5 VOLVO-EC<br>6 DATCON<br>7 SGX<br>8 SGD<br>9 SGH<br>10 PT100<br>11~15 Reserved | Defined resistance's range is (0~6)KΩ, default is SGX sensor. |
| 2   | Pressure Sensor    | 0 Not used<br>1 Custom Res Curve<br>2 Custom 4-20mA curve<br>3 VDO 10Bar<br>4 CURTIS<br>5 VOLVO-EC<br>6 DATCON 10Bar<br>7 SGX<br>8 SGD<br>9 SGH<br>10~15 Reserved | Defined resistance's range is (0~6)KΩ, default is SGX sensor. |
| 3   | Fuel Level Sensor  | 0 Not used<br>1 Custom Res Curve<br>2 Custom 4-20mA curve<br>3 SGD<br>4 SGH<br>5~15 Reserved  | Defined resistance's range is (0~6)KΩ, default is SGH sensor. |

**NOTE:** User should take the controller apart to change the jumper hat from resistor side to current side if your pump unit fitted with 4~20mA sensor.

## 7.5 CONDITIONS OF CRANK DINSCONNECT SELECTION

| No. | Setting description         |
|-----|-----------------------------|
| 0   | Engine Speed                |
| 1   | Oil pressure                |
| 2   | Oil pressure + Engine Speed |

**NOTE:**

1. There are 3 conditions to make starter disconnected with engine. Engine speed and oil pressure both can be used separately. We recommend that oil pressure should be using with engine speed together, in order to make the starter motor is separated with engine immediately and can check crank disconnect exactly.
2. Engine speed is the magnetic equipment which be installed in starter for detecting flywheel teeth.
3. When set as engine speed, must ensure that the number of flywheel teeth is as same as setting, otherwise, “over speed shutdown” or “under speed shutdown” may be caused.
4. If pump unit without engine speed sensor, please don't select corresponding items, otherwise, “start fail” or “loss speed signal” maybe caused.
5. If genset without oil pressure sensor, please don't select corresponding items.

## 7.6 MAINTENANCE (FORM 6)

| Items                   | Content   | Description   |
|-------------------------|---|---|
| Enable Select           | 0: Disable; 1: Enable                                       | Used for setting the current maintenance function.  |
| Maintenance Interval    | (0-30000)h  | The time interval between two maintenance.  |
| Maintenance Due         | 0: No Action;<br>1: Warn;<br>2: Shutdown;<br>3: Indication. | They are the alarm action types when the maintenance time is due.                                 |
| Prealarm A              | (0-30000)h  | Maintenance remaining time  |
| Prealarm A Action       | 0: No Action;<br>1: Warn;<br>2: Shutdown;<br>3: Indication. | They are the alarm action types when the maintenance remaining time is left prealarm A time only. |
| Prealarm B              | (0-30000)h  | Maintenance remaining time  |
| Prealarm B Action       | 0: No Action;<br>1: Warn;<br>2: Shutdown;<br>3: Indication. | They are the alarm action types when the maintenance remaining time is left prealarm B time only. |
| Timer Mode              | 0: Running Time;<br>1: Real Time Clock                      | The maintenance timer mode  |
| Reset Maintenance Alarm |   | Reset maintenance alarm when the maintenance time is due.   |
| Description             |   | The maintenance name are user-set. E.g. Change oil  |


## 8 PARAMETERS SETTING

1. Please change the controller parameters when generator is in standby mode only (e. g. Crank disconnect conditions selection, digital input, digital output, various delay), otherwise, shutdown and other abnormal conditions may occurs.
2. Maximum set value must over minimum set value in case that the condition of too high as well as too low will happen.
3. When setting the warning alarm, please set the correct return value; otherwise, maybe there is abnormal alarm. When setting the maximum value, the return value must less than set value; When setting the minimum value, the return value must over than set value.
4. Digital input could not be set as same items; otherwise, there are abnormal functions. However, the digital output can be set as same items.

SmartGen

## 9 SENSOR SELECT

- 1) When reselect sensors, the sensor curve will be transferred into the standard value. For example, if temperature sensor is SGX (120°C resistor type), its sensor curve is SGX (120°C resistor type); if select the SGD (120°C resistor type), the temperature sensor curve is SGD curve.
- 2) When there is difference between standard sensor curves and using sensor, user can adjust it in “curve type”.
- 3) When input the sensor curve, X value (resistor) must be input from small to large, otherwise, mistake occurs.
- 4) If select sensor type as “None”, sensor curve is not working and LCD does not display the sensor information.
- 5) If there is alarm switch only for the select sensor, user must set the sensor as “None”, otherwise, maybe shutdown or warning occurs.
- 6) The headmost or backmost values in the vertical coordinates can be set as same as below,




**Common unit conversion table**

|                      | N/m <sup>2</sup> (pa) | kgf/cm <sup>2</sup>   | bar                   | (p/in <sup>2</sup> .psi) |
|----------------------|-----------------------|-----------------------|-----------------------|--------------------------|
| 1Pa                  | 1                     | 1.02x10 <sup>-5</sup> | 1x10 <sup>-5</sup>    | 1.45x10 <sup>-4</sup>    |
| 1kgf/cm <sup>2</sup> | 9.8x10 <sup>4</sup>   | 1                     | 0.98                  | 14.2                     |
| 1bar                 | 1x10 <sup>5</sup>     | 1.02                  | 1                     | 14.5                     |
| 1psi                 | 6.89x10 <sup>3</sup>  | 7.03x10 <sup>-2</sup> | 6.89x10 <sup>-2</sup> | 1                        |



### 10 TYPICAL APPLICATION




Smart



## 11 INSTALLATION

Controller is panel built-in design; it is fixed by clips when installed.



### 1) Battery Voltage Input

**NOTE:** APC715 controller can suit for widely range of battery voltage DC(8~35)V. Negative of battery must be connected with the engine shell soundly. The diameter of wire which from power supply to battery must be over  $2.5\text{mm}^2$ . If floating charge configured, please firstly connect output wires of charger to battery's positive and negative directly, then, connect wires from battery's positive and negative to controller's corresponding input ports in order to prevent charge disturbing the controller's normal working.

### 2) Speed Sensor Input

**NOTE:** Speed sensor is the magnetic equipment which be installed in starter and for detecting flywheel teeth. Its connection wires to controller should apply for 2 cores shielding line. The shielding layer should connect to shielding GND terminal in controller while another side is hanging in air. The else two signal wires are connected to MP1 and MP2 terminals, moreover, MP2 has already connected to B- innerly. The output voltage of speed sensor should be within AC(1~24)V (effective value) during the full speed. AC12V is recommended (in rated speed). When install the speed sensor, let the sensor is spun to contacting flywheel first, then, port out 1/3 lap, and lock the nuts of sensor at last.

### 3) Output And Expansion Relay

**NOTE:** All outputs of controller are relay contact output type. If need to expand the relays, please add freewheel diode to both ends of expand relay's coils (when coils of relay has DC current) or, add resistance-capacitance return circuit (when coils of relay has AC current), in order to prevent disturbance to controller or others equipment.

## 12 CONNECTIONS OF CONTROLLER WITH J1939 ENGINE

### 12.1 CUMMINS ISB/ISBE

| Terminals of controller | Connector B   | Remark   |
|-------------------------|---|--|
| Fuel relay output       | 39  |  |
| Start relay output      | -   | Connect with starter coil directly                 |
| Auxiliary output port 1 | Expand 30A relay, battery voltage of 01,07,12,13 is supplied by relay | ECU power<br>Set Auxiliary output 1 as "ECU power" |

| Terminals of controller | 9 pins connector | Remark   |
|-------------------------|------------------|--|
| CAN GND                 | SAE J1939 shield | CAN communication shielding line(connect with ECU terminal only) |
| CAN(H)                  | SAE J1939 signal | Impedance 120Ω connecting line is recommended.                   |
| CAN(L)                  | SAE J1939 return | Impedance 120Ω connecting line is recommended.                   |

**Engine type: Cummins ISB**

### 12.2 CUMMINS QSL9

Suitable for CM850 engine control mode

| Terminals of controller | 50 pins connector | Remark                           |
|-------------------------|-------------------|----------------------------------|
| Fuel relay output       | 39                |                                  |
| Start relay output      | -                 | Connect to starter coil directly |

| Terminals of controller | 9 pins connector   | Remark   |
|-------------------------|--------------------|--|
| CAN GND                 | SAE J1939 shield-E | CAN communication shielding line(connect with ECU terminal only) |
| CAN(H)                  | SAE J1939 signal-C | Impedance 120Ω connecting line is recommended.                   |
| CAN(L)                  | SAE J1939 return-D | Impedance 120Ω connecting line is recommended.                   |

**Engine type: Cummins-CM850**

### 12.3 CUMMINS QSM11(import)

It is suitable for CM570 engine control module. Engine type is QSM11 G1, QSM11 G2.

| Terminals of controller | C1 connector | Remark  |
|-------------------------|--------------|---|
| Fuel relay output       | 5&8          | Outside expand relay, when fuel output, making port 5 and port 8 of C1 be connected |
| Start relay output      | -            | Connect to starter coil directly  |

| Terminals of controller | 3 pins data link connector | Remark   |
|-------------------------|----------------------------|--|
| CAN GND                 | C                          | CAN communication shielding line(connect with ECU terminal only) |
| CAN(H)                  | A                          | Impedance 120Ω connecting line is recommended.                   |
| CAN(L)                  | B                          | Impedance 120Ω connecting line is recommended.                   |

**Engine type: Cummins ISB**

### 12.4 CUMMINS QSX15-CM570

It is suitable for CM570 engine control module. Engine type is QSX15.

| Terminals of controller | 50 pins connector | Remark                           |
|-------------------------|-------------------|----------------------------------|
| Fuel relay output       | 38                | Oil spout switch                 |
| Start relay output      | -                 | Connect to starter coil directly |

| Terminals of controller | 9 pins connector   | Remark   |
|-------------------------|--------------------|--|
| CAN GND                 | SAE J1939 shield-E | CAN communication shielding line(connect with ECU terminal only) |
| CAN(H)                  | SAE J1939 signal-C | Impedance 120Ω connecting line is recommended.                   |
| CAN(L)                  | SAE J1939 return-D | Impedance 120Ω connecting line is recommended.                   |

**Engine type: Cummins QSX15-CM570**

## 12.5 CUMMINS GCS-MODBUS

It is suitable for GCS engine control module. Use RS485-MODBUS to read information of engine. Engine types are QSX15, QST30, QSK23 / 45/60/78 and so on.

| Terminals of controller | D-SUB connector 06 | Remark  |
|-------------------------|--------------------|---|
| Fuel relay output       | 5&8                | Outside expand relay, when fuel output, making port 05 and 08 of the connector 06 be connected. |
| Start relay output      | -                  | Connect to starter coil directly  |

| Terminals of controller | D-SUB connector 06 | Remark   |
|-------------------------|--------------------|--|
| RS485 GND               | 20                 | CAN communication shielding line(connect with ECU terminal only) |
| RS485+                  | 21                 | Impedance 120Ω connecting line is recommended.                   |
| RS485-                  | 18                 | Impedance 120Ω connecting line is recommended.                   |

**Engine type: Cummins QSK-MODBUS, Cummins QST-MODBUS, Cummins QSX-MODBUS**

## 12.6 CUMMINS QSM11

| Terminals of controller | OEM connector of engine | Remark   |
|-------------------------|-------------------------|--|
| Fuel relay output       | 38                      |  |
| Start relay output      | -                       | Connect with starter coil directly   |
| CAN GND                 | -                       | CAN communication shielding line(connect with controller's this terminal only) |
| CAN(H)                  | 46                      | Impedance 120Ω connecting line is recommended.                                 |
| CAN(L)                  | 37                      | Impedance 120Ω connecting line is recommended.                                 |

**Engine type: common J1939**

**12.7 CUMMINS QSZ13**

| Terminals of controller | OEM connector of engine | Remark   |
|-------------------------|-------------------------|--|
| Fuel relay output       | 45                      |  |
| Start relay output      | -                       | Connect to starter coil directly   |
| Programmable output 1   | 16&41                   | Setting to idle speed control, normally open output. Making 16 connect to 41 during high-speed running of controller via external expansion relay.                   |
| Programmable output 2   | 19&41                   | Setting to pulse raise speed control, normally open output. Making 19 connect with 41 for 0.1s during high-speed warming of controller via external expansion relay. |
| CAN GND                 | -                       | CAN communication shielding line(connect with controller's this terminal only)   |
| CAN(H)                  | 1                       | Impedance 120Ω connecting line is recommended.   |
| CAN(L)                  | 21                      | Impedance 120Ω connecting line is recommended.   |

**Engine type:** QSZ13, speed regulation can be implemented.

**12.8 DETROIT DIESEL DDEC III / IV**

| Terminals of controller | CAN port of engine  | Remark   |
|-------------------------|---|--|
| Fuel relay output       | Expand 30A relay, battery voltage of ECU is supplied by relay |  |
| Start relay output      | -   | Connect to starter coil directly   |
| CAN GND                 | -   | CAN communication shielding line (connect with controller's terminal only) |
| CAN(H)                  | CAN(H)  | Impedance 120Ω connecting line is recommended.                             |
| CAN(L)                  | CAN(L)  | Impedance 120Ω connecting line is recommended.                             |

**Engine type:** Common J1939

**12.9 DEUTZ EMR2**

| Terminals of controller | F connector  | Remark  |
|-------------------------|--|---|
| Fuel relay output       | Expand 30A relay, battery voltage of 14 is supplied by relay. Fuse is 16A. |   |
| Start relay output      | -  | Connect to starter coil directly  |
| -                       | 1  | Connect to battery negative pole  |
| CAN GND                 | -  | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | 12   | Impedance 120Ω connecting line is recommended.                            |
| CAN(L)                  | 13   | Impedance 120Ω connecting line is recommended.                            |

**Engine type: VolvoEDC4**
**12.10 JOHN DEERE**

| Terminals of controller | 21 pins connector | Remark  |
|-------------------------|-------------------|---|
| Fuel relay output       | G,J               |   |
| Start relay output      | D                 |   |
| CAN GND                 | -                 | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | V                 | Impedance 120Ω connecting line is recommended.                            |
| CAN(L)                  | U                 | Impedance 120Ω connecting line is recommended.                            |

**Engine type: John Deere**
**12.11 MTU MDEC**

Suitable for MTU engines, 2000 series, 4000series

| Terminals of controller | X1 connector | Remark   |
|-------------------------|--------------|--|
| Fuel relay output       | BE1          |  |
| Start relay output      | BE9          |  |
| CAN GND                 | E            | CAN communication shielding line(connect with one terminal only) |
| CAN(H)                  | G            | Impedance 120Ω connecting line is recommended.                   |
| CAN(L)                  | F            | Impedance 120Ω connecting line is recommended.                   |

**Engine type: MTU-MDEC-303**
**12.12 MTU ADEC(SMART module)**

It is suitable for MTU engine with ADEC (ECU8) and SMART module.

| Terminals of controller | ADEC (X1port) | Remark  |
|-------------------------|---------------|---|
| Fuel relay output       | X1 10         | X1 Terminal 9 Connected to negative of battery  |
| Start relay output      | X1 34         | X1 Terminal 33 Connected to negative of battery |

| Terminals of controller | SMART (X4 port) | Remark   |
|-------------------------|-----------------|--|
| CAN GND                 | X4 3            | CAN communication shielding line(connect to controller's this terminal only) |
| CAN(H)                  | X4 1            | Impedance 120Ω connecting line is recommended.                               |
| CAN(L)                  | X4 2            | Impedance 120Ω connecting line is recommended.                               |

**Engine type: MTU-ADEC**
**12.13 MTU ADEC(SAM module)**

It is suitable for MTU engine with ADEC (ECU7) and SAM module.

| Terminals of controller | ADEC (X1port) | Remark  |
|-------------------------|---------------|---|
| Fuel relay output       | X1 43         | X1 Terminal 28 Connected to negative of battery |
| Start relay output      | X1 37         | X1 Terminal 22 Connected to negative of battery |

| Terminals of controller | SAM (X23 port) | Remark   |
|-------------------------|----------------|--|
| CAN GND                 | X23 3          | CAN communication shielding line(connect with controller's this terminal only) |
| CAN(H)                  | X23 2          | Impedance 120Ω connecting line is recommended.                                 |
| CAN(L)                  | X23 1          | Impedance 120Ω connecting line is recommended.                                 |

**Engine type: Common J1939**



### 12.14 PERKINS

It is suitable for ADEM3/ ADEM4 engine control module. Engine type is 2306, 2506, 1106, and 2806.

| Terminals of controller | Connector     | Remark  |
|-------------------------|---------------|---|
| Fuel relay output       | 1,10,15,33,34 |   |
| Start relay output      | -             | Connect to starter coil directly  |
| CAN GND                 | -             | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | 31            | Impedance 120Ω connecting line is recommended.                            |
| CAN(L)                  | 32            | Impedance 120Ω connecting line is recommended.                            |

**Engine type: Perkins**

### 12.15 SCANIA

It is suitable for S6 engine control module. Engine type is DC9, DC12, and DC16.

| Terminals of controller | B1 connector | Remark  |
|-------------------------|--------------|---|
| Fuel relay output       | 3            |   |
| Start relay output      | -            | Connect to starter coil directly  |
| CAN GND                 | -            | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | 9            | Impedance 120Ω connecting line is recommended.                            |
| CAN(L)                  | 10           | Impedance 120Ω connecting line is recommended.                            |

**Engine type: Scania**

### 12.16 VOLVO EDC3

Suitable engine control mode is TAD1240, TAD1241, and TAD1242.

| Terminals of controller | "Stand alone" connector | Remark   |
|-------------------------|-------------------------|--|
| Fuel relay output       | H                       |  |
| Start relay output      | E                       |  |
| Programmable output 1   | P                       | ECU power supply<br>Set programmable output 1 as "ECU power" |

| Terminals of controller | "Data bus" connector | Remark  |
|-------------------------|----------------------|---|
| CAN GND                 | -                    | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | 1                    | Impedance 120Ω connecting line is recommended.                            |
| CAN(L)                  | 2                    | Impedance 120Ω connecting line is recommended.                            |

**Engine type: Volvo**

**▲NOTE:** When this engine type is selected, preheating time should be set to at least 3 seconds.

**12.17 VOLVO EDC4**

Suitable engine types are TD520, TAD520 (optional), TD720, TAD720 (optional), TAD721, TAD722, and TAD732.

| Terminals of controller | Connector  | Remark  |
|-------------------------|--|---|
| Fuel relay output       | Expanded 30A relay, and relay offers battery voltage for terminal14. Fuse is 16A |   |
| Start relay output      | -  | Connect to starter coil directly  |
|                         | 1  | Connected to negative of battery  |
| CAN GND                 | -  | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | 12   | Impedance 120Ω connecting line is recommended.                            |
| CAN(L)                  | 13   | Impedance 120Ω connecting line is recommended.                            |

**Engine type: VolvoEDC4**

**12.18 VOLVO-EMS2**

Volvo Engine types are TAD734, TAD940, TAD941, TAD1640, TAD1641, and TAD1642.

| Terminals of controller | Engine's CAN port | Remark  |
|-------------------------|-------------------|---|
| Programmable output 1   | 6                 | ECU stop<br>Set programmable output 1 as "ECU stop"                       |
| Programmable output 2   | 5                 | ECU power<br>Set programmable output 2 as "ECU power"                     |
|                         | 3                 | Negative power  |
|                         | 4                 | Positive power  |
| CAN GND                 | -                 | CAN communication shielding line(connect with controller's terminal only) |
| CAN(H)                  | 1(Hi)             | Impedance 120Ω connecting line is recommended.                            |
| CAN(L)                  | 2(Lo)             | Impedance 120Ω connecting line is recommended.                            |

**Engine type: Volvo-EMS2**, speed regulation can be implemented.

**▲ NOTE:** When this engine type is selected, preheating time should be set to at least 3 seconds.

**12.19 Yuchai**

It is suitable for BOSCH common rail pump engine.

| Terminals of controller | Engine 42 pins port | Remark   |
|-------------------------|---------------------|--|
| Fuel relay output       | 1.40                | Connect to engine ignition lock  |
| Start relay output      | -                   | Connect to starter coil directly   |
| CAN GND                 | -                   | CAN communication shielding line(connect with controller's this terminal only) |
| CAN(H)                  | 1.35                | Impedance 120Ω connecting line is recommended.                                 |
| CAN(L)                  | 1.34                | Impedance 120Ω connecting line is recommended.                                 |

| Battery          | Engine 2 pins | Remark                            |
|------------------|---------------|-----------------------------------|
| Battery negative | 1             | Wire diameter: 2.5mm <sup>2</sup> |
| Battery positive | 2             | Wire diameter: 2.5mm <sup>2</sup> |

**Engine type: BOSCH**, speed regulation can be implemented.

## 12.20 Weichai

It is suitable for Weichai BOSCH common rail pump engine.

| Terminals of controller | Engine port | Remark   |
|-------------------------|-------------|--|
| Fuel relay output       | 1.40        | Connect to engine ignition lock  |
| Start relay output      | 1.61        |  |
| CAN GND                 | -           | CAN communication shielding line(connect to the controller at this end only) |
| CAN(H)                  | 1.35        | Impedance 120Ω connecting line is recommended.                               |
| CAN(L)                  | 1.34        | Impedance 120Ω connecting line is recommended.                               |

**Engine type: GTSC1**, speed regulation can be implemented.

**▲ NOTE:** If there is any question about connection between controller and ECU communication, please feel free to contact Smartgen's service.

## 13 USB

Users can set the controller's parameters and monitor the controller's status via USB port using the test software which provided by Smatgen company. USB port is active in stop mode only while at other times it couldn't be detected by PC.

**14 FAULT FINDING**

| Symptoms                                      | Possible Solutions   |
|---|--|
| Controller no response with power.            | Check starting batteries;<br>Check controller connection wirings;<br>Check DC fuse.  |
| Genset shutdown                               | Check the water/cylinder temperature is too high or not;<br>Check DC fuse.   |
| Controller emergency stop                     | Check emergence stop button is correct or not;<br>Check whether the positive of starting battery is connected with the emergency stop input;<br>Check whether the circuit is open.   |
| Low oil pressure alarm after crank disconnect | Check the oil pressure sensor and its connections.   |
| High water temp. alarm after crank disconnect | Check the temperature sensor and its connections.  |
| Shutdown Alarm in running                     | Check related switch and its connections according to the information on LCD;<br>Check programmable inputs.  |
| Crank not disconnect                          | Check fuel oil circuit and its connections;<br>Check starting batteries;<br>Check speed sensor and its connections;<br>Refer to engine manual.   |
| Starter no response                           | Check starter connections;<br>Check starting batteries.  |
| RS485 COM Fail                                | Check connections;<br>Check setting of COM port is correct or not;<br>Check RS485's connections of A and B is reverse connect or not;<br>Check RS485 transfer model whether damage or not;<br>Check communication port of PC whether damage. |
| ECU COM Fail                                  | Check connections of CAN high and low polarity;<br>Check if correctly connected of 120Ω resistor;<br>Check if engine type is correct;<br>Check if connections from controller to engine and outputs setting are correct.                     |
| ECU Warning or Shutdown                       | Get information from LCD of alarm page;<br>If there is detailed alarm, check engine according to description. If not, please refer to engine manual according to SPN alarm code.   |