



SmartGen
ideas for power

HRC200

INDUSTRIAL REMOTE CONTROL

USER MANUAL



SMARTGEN (ZHENGZHOU) TECHNOLOGY CO., LTD.



Chinese trademark

SmartGen English trademark

SmartGen – make your generator *smart*

SmartGen Technology Co., Ltd.

No.28 Jinsuo Road

Zhengzhou

Henan Province

P. R. China

Tel: +86-371-67988888/67981888/67992951

+86-371-67981000(overseas)

Fax: +86-371-67992952

Email: sales@smartgen.cn

Web: www.smartgen.com.cn / www.smartgen.cn

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to Smartgen Technology at the address above.

Any reference to trademarked product names used within this publication is owned by their respective companies.

SmartGen Technology reserves the right to change the contents of this document without prior notice.

Table 1 Software Version

Date	Version	Note
2021-07-02	1.0	Original release.



CONTENT

1	OVERVIEW.....	4
2	PERFORMANCE AND CHARACTERISTICS	4
3	SPECIFICATION	5
4	PANEL AND WIRING TERMINAL DESCRIPTION.....	6
4.1	HRC200R REMOTE CONTROL PANEL INDICATORS AND KEYS.....	6
4.2	HRC200M RECEIVER PANEL INDICATORS AND INTERNAL KEYS.....	8
4.3	COMMUNICATION CHANNEL CONFIGURATION	8
4.4	PAIRING.....	9
4.5	RS485 INTERFACE.....	10
4.6	RECEIVER WIRING TERMINAL.....	11
5	PROGRAMMABLE PARAMETERS.....	12
5.1	PC PARAMETER SETTING	12
5.2	PARAMETER RANGE AND DEFINITION	12
6	SYSTEM APPLICATION DIAGRAM	13
7	OVERALL AND INSTALLATION DIMENSIONS	15
7.1	REMOTE CONTROL OVERALL DIMENSION	15
7.2	RECEIVER OVERALL DIMENSION.....	15
8	TROUBLESHOOTING	16

1 OVERVIEW

HRC200 is a long-distance wireless remote control with LoRa wireless chip transmission and remote control distance of more than 200m. Used with engine controller, it can realize remote start, stop, load, unload, emergency stop and other functions. HRC200 adopts fully sealed structure, IP65 protection level, which can effectively prevent dust, water or others from entering the controller, making the controller operate stably and reliably, suitable for field, mining, urban construction and other application sites with complex working conditions.

2 PERFORMANCE AND CHARACTERISTICS

HRC200 industrial remote control is composed of remote control HRC200R and receiver HRC200M, applying LoRa wireless transmission chip.

Remote Control:

- Can realize remote start, stop, load, unload, emergency stop and other functions, indicate engine running/alarm, remote control battery, command send/receive status;
- Powered by 4 AA batteries;
- With remote control distance of more than 200m, 15 optional communication channels;
- Whole protection level can reach IP65.

Receiver:

- With RS485 interface, 5 output ports and 2 input ports, can control engine controller via RS485 interface or relay output port;
- With power, RS485, LoRa communication status indicator; 15 optional communication channels;
- Supply range DC (8~35)V;
- Can set its parameters via PC;
- Modular structure design, anti-flaming ABS plastic shell, light weight, compact structure and easy installation;
- Standard Π type 35mm guide rail installation or screw installation is applied.

3 SPECIFICATION

Table 2 Technical Parameters

Item	Contents
Remote Control HRC200R	
Working Voltage	Powered by 4 AA alkaline batteries.
Overall Consumption	Can last about 72 hours.
Case Dimension (LxWxH)	156.9mmx63mmx53mm (without antenna)
Working Conditions	Temperature: (-25~+70)°C Humidity: (20~95)%RH Actual working temperature is limited by battery characteristics.
Storage Condition	Temperature: (-30~+80)°C
Weight	0.2kg (without battery)
Receiver HRC200M	
Working Voltage	DC (8~35)V
Overall Consumption	≤1.2W
Aux. Input Port	B- connected is active.
Aux. Output Port	Relay normally open volt-free output, specification DC30V/2A
RS485 Interface	Isolated, half-duplex, 2400/4800/9600/19200 baud rate can be set, Modbus-RTU communication protocol, longest communication distance 1,000m.
LINK	SmartGen special interface for program upgrade.
Case Dimension (LxWxH)	105mmx72.5mmx34mm
Working Conditions	Temperature: (-25~+70)°C Humidity: (20~95)%RH
Storage Condition	Temperature: (-30~+80)°C
Weight	0.2kg

4 PANEL AND WIRING TERMINAL DESCRIPTION

4.1 HRC200R REMOTE CONTROL PANEL INDICATORS AND KEYS



Fig.1 Remote Control Panel Description

Table 3 Indicators Description

Indicators	Description
Power Status	Indicator flashes yellow during pairing process; Indicator keeps red on when battery voltage is low; it keeps green on when battery voltage is normal.
Connection Status	Indicator flashes yellow during pairing process; Press the key, indicator flashes red once when sending, indicator flashes green once when receiving success; Indicator displays yellow when communication abnormal situation lasts over 5s; indicator flashes yellow once after pressing the key.
Common Alarm/Running Status	Indicator flashes yellow during pairing process; Indicator keeps green on during normal running; Indicator flashes red when common alarm occurs; It will extinguish when communication abnormal situation lasts over 5s.

Table 4 Keys Description

Icon	Key	Description
	Power	Long press this key 2s to power on the remote control, then long press this key 2s again to power off the remote control.
	Start	Press this key to send start command.
	Stop	Press this key to send stop command.
	F1	Press this key to send F1 command. (see the following description.)
	F2	Long press this key 6s to enter pairing, press it again during the pairing process to cancel pair; Press this key to send F2 command. (see the following description.)
	Load	Press this key to send load command.
	Unload	Press this key to send unload command.
	Emergency Stop	Press this key to send emergency stop command, turn it clockwise to reset. (When this key is pressed, load/unload/start/F1/F2 keys are all inactive, communication status indicator keeps flashing red.)
	No Key Operation	If can't receive the data and no key operation within 10 minutes, remote control power will automatically shut off.

4.2 HRC200M RECEIVER PANEL INDICATORS AND INTERNAL KEYS




Fig.2 Receiver Panel Description

Table 5 Indicators and Keys Description

Indicator	Description
POWER (Indicator: green)	Always illuminating: power is normal; Always extinguishing: power is abnormal.
RS485 (Indicator: green)	Flashing: RS485 communication is normal; Always extinguishing: RS485 communication fails.
LoRa (Indicator: green)	Flashing: communication with remote control is normal; Always extinguishing: communication with remote control fails.
PAIR (key)	Long press it 6s to enter pairing mode; Press it again after entering pairing mode can cancel pair.

4.3 COMMUNICATION CHANNEL CONFIGURATION

The remote control configures the communication channel via jumper cap. Jumper cap leftmost and rightmost positions are inactive, it is 1 when the middle four positions are connected to the jumper cap, otherwise it is 0. The default jumper cap position is 1111 (515MHz).




Fig.3 Communication Channel Configuration

Table 6 Communication Channel Configuration Steps

Step	Description
1	Turn the bottom screw cover anticlockwise to open the base.
2	Change the middle four jumper cap positions to configure the communication channel and replace the battery at the same time.
3	Turn the bottom screw cover clockwise to close the base.

The receiver configures the communication channel via dial switch. It is 1 when the dial switch is set to ON position, otherwise it is 0. The default dial switch position is 1111 (515MHz).

Table 7 Communication Channels

No.		Channel Frequency (MHz)
1	0001	445
2	0010	450
3	0011	455
4	0100	460
5	0101	465
6	0110	470
7	0111	475
8	1000	480
9	1001	475
10	1010	485
11	1011	490
12	1100	495
13	1101	500
14	1110	505
15	1111	515

It is 1 when the dial switch is set to ON position, otherwise it is 0.

NOTE: When the dial switch is configured as 0000, it is configuration mode (refer to 4.1).

4.4 PAIRING

Table 8 Pairing Description

Method	Process
Method 1: Remote control waits for receiver pairing.	<ol style="list-style-type: none"> 1. Turn the remote control and receiver to the same channel. (see the communication channel configuration, default channel is 515MHz.) 2. Turn on the remote control power, its power indicator keeps on. Long press F2 key 6s, all indicators are flashing yellow, which means entering pairing mode. Press F2 key again during LoRa pairing can cancel pair. 3. Turn on the receiver power, POWER indicator keeps on. Insert a slender needle less than 3.5mm in diameter into the PAIR hole vertically, then long press PAIR key 6s.

Method	Process
	4. If pairing successfully within 60s, remote control COMM indicator extinguishes after illuminating green 2s, receiver LoRa and RS485 indicators extinguish, POWER indicator keeps green for a long time. Otherwise, COMM indicator keeps red for a long time when the pairing fails.
Method 2: Receiver waits for remote control pairing.	1. Turn the remote control and receiver to the same channel. (see the communication channel configuration, default channel is 515MHz.)
	2. Turn on the receiver power, POWER indicator keeps on. Insert a slender needle less than 3.5mm in diameter into the PAIR hole vertically, then long press PAIR key 6s, LoRa, RS485 and POWER indicator flash green. Press PAIR key again during LoRa pairing can cancel pair.
	3. Turn on the remote control power, its power indicator keeps on. Long press F2 key 6s.
	4. If pairing successfully within 60s, remote control COMM indicator extinguishes after illuminating green 2s, receiver LoRa and RS485 indicators extinguish, POWER indicator keeps green for a long time. Otherwise, COMM indicator keeps red for a long time when the pairing fails.

4.5 RS485 INTERFACE

Receiver connects to engine controller via RS485 interface, 120Ω terminal matching resistor is recommended to use (when RS485 A(+) and TR terminal is short connected), RS485 communication line must use twisted shielded pair line.




Fig.4 RS485 Connection Diagram

4.6 RECEIVER WIRING TERMINAL




Fig.5 Mask Diagram

Table 9 Wiring Terminal Description

No.	Function	Cable Size	Remark
1	COM	0.75mm ²	Relay common port.
2	AUX. OUTPUT5	0.75mm ²	Normally open volt-free output, capacity DC30V/2A.
3	AUX. OUTPUT4	0.75mm ²	Normally open volt-free output, capacity DC30V/2A.
4	AUX. OUTPUT3	0.75mm ²	Normally open volt-free output, capacity DC30V/2A.
5	AUX. OUTPUT2	0.75mm ²	Normally open volt-free output, capacity DC30V/2A.
6	AUX. OUTPUT1	0.75mm ²	Normally open volt-free output, capacity DC30V/2A.
7	TR	/	RS485 communication line uses twisted shielded pair line. When 120Ω terminal matching resistor is required, A(+) and TR terminal should be short connected.
8	RS485 A(+)	0.5mm ²	
9	RS485 B(-)	0.5mm ²	
10	AUX. INPUT2	0.75mm ²	B- connected is active.
11	AUX. INPUT1	0.75mm ²	B- connected is active.
12	B+	0.75mm ²	Externally connects power positive.
13	B-	0.75mm ²	Externally connects power negative.

5 PROGRAMMABLE PARAMETERS

5.1 PC PARAMETER SETTING

Before operation, please remember the dial switch position of HRC200M, then set switch to configuration mode (namely 0000 position). PC connects to receiver via RS485 communication conversion module, then the related parameter configuration of receiver can be done via PC software. After the configuration is completed, dial switch must recover to previous position.




Fig.6 PC Configuration Interface

5.2 PARAMETER RANGE AND DEFINITION

Table 10 Parameter Content and Range

No.	Item	Range	Default	Description
1	Comm. Address	1-254	1	
2	Baud Rate	(0-3)	2	0: 2400bps 1: 4800bps 2: 9600bps 3: 19200bps
3	Parity Bit	(0-2)	0	0: No Parity 1: Odd Parity

No.	Item	Range	Default	Description
				2: Even Parity
4	Stop Bit	(0-1)	0	0: 1-bit 1: 2-bit
5	Aux. Input 1	(0-9)	1	0: Not Used 1: Remote Control Inhibit 2: Simulate Start Key 3: Simulate Stop Key
6	Aux. Input 2	(0-9)	0	4: Simulate Unload Key 5: Simulate Load Key 6: Simulate F1 Key 7: Simulate F2 Key 8: Simulate Running Status 9: Simulate Alarm Status
7	Aux. Output 1	(0-6)	5	0: Not Used
8	Aux. Output 2	(0-6)	6	1: Start Control
9	Aux. Output 3	(0-6)	0	2: Stop Control
10	Aux. Output 4	(0-6)	0	3: Unload Control
11	Aux. Output 5	(0-6)	0	4: Load Control 5: F1 Control 6: F2 Control
12	Aux. Output 1 Output Delay	(0-999.9)s	1.0s	When it is set as 0, relay continuously outputs when the remote control key is firstly pressed, relay stops output when the key is pressed again. When it is set as other values, relay disconnects output after outputting set delay value.
13	Aux. Output 2 Output Delay	(0-999.9)s	1.0s	
14	Aux. Output 3 Output Delay	(0-999.9)s	1.0s	
15	Aux. Output 4 Output Delay	(0-999.9)s	1.0s	
16	Aux. Output 5 Output Delay	(0-999.9)s	1.0s	

6 SYSTEM APPLICATION DIAGRAM

Remote control communicates with receiver via LoRa, engine controller and receiver can be controlled by RS485 communication or digital input/output port.



Fig.7 HRC200 System Application Diagram




Fig.8 HRC200M Digital Control Application Diagram

Table 11 Parameter Configuration

	No.	Item	Parameter
HRC200	1	Aux. Input 1	8: Running Status
	2	Aux. Input 2	9: Alarm Status
	3	Aux. Output 1	2: Stop Control
	4	Aux. Output 2	4: Load Control
	5	Aux. Output 3	3: Unload Control
	6	Aux. Output 4	1: Start Control
ACC7100A	1	Aux. Output 2	38: Start Success Output
	2	Aux. Output 3	42: Common Alarm
	3	Aux. Input 3	34: Simulate Stop Key
	4	Aux. Input 4	35: Simulate Load Key
	5	Aux. Input 5	36: Simulate Unload Key
	6	Aux. Input 6	37: Simulate Start Key

7 OVERALL AND INSTALLATION DIMENSIONS

7.1 REMOTE CONTROL OVERALL DIMENSION

Unit: mm




Fig.9 HRC200R Overall Dimension

7.2 RECEIVER OVERALL DIMENSION

Installation method can be 35mm guide rail installation or screw (M4) installation. Overall dimension is as follows:

Unit: mm




Fig.10 HRC200M Overall Dimension




Fig.11 HRC200M Guide Rail Installation




Fig.12 HRC200M Screw Installation

8 TROUBLESHOOTING

Table 12 Troubleshooting

Symptom	Possible Solutions
Receiver Inactive for Power	Check the power supply.
RS485 Comm. Abnormal	Check the connection line; Check whether communication address, baud rate, parity bit, stop bit set is correct; Check whether A(+) and B(-) of RS485 are reversely connected; Try to connect 120Ω terminal matching resistor.
Pairing Failure	Check whether the channel of remote control and receiver is same.
Receiver and PC Fails to Connect	Check whether the receiver dial switch is set to 0000 position.
Remote Control Key Inactive	Check whether the emergency stop key is pressed, when it is pressed, other function keys are inactive.