




SmartGen
ideas for power

HAT833

THREE POWER ATS CONTROLLER

USER MANUAL



SMARTGEN (ZHENGZHOU) TECHNOLOGY CO., LTD.



Chinese trademark

SmartGen English trademark

SmartGen — make your generator *smart*

SmartGen Technology Co., Ltd.

No.28 Jinsuo Road

Zhengzhou

Henan Province

P. R. China

Tel: 0086-371-67988888/67981888

0086-371-67991553/67992951

0086-371-67981000(overseas)

Fax: 0086-371-67992952

Web: www.smartgen.com.cn

www.smartgen.cn

Email: sales@smartgen.cn

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder.

Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to SmartGen Technology at the address above.

Any reference to trademarked product names used within this publication is owned by their respective companies.

SmartGen Technology reserves the right to change the contents of this document without prior notice.

Table 1 - Software Version

Date	Version	Note
2018-10-16	1.0	Original release.
2018-12-13	1.1	Modified controller front panel picture.

CONTENT

1 OVERVIEW	4
2 PERFORMANCE AND CHARACTERISTICS	5
3 SPECIFICATION	6
4 MEASURE AND DISPLAY DATA	7
5 OPERATION.....	8
5.1 INDICATORS.....	8
5.2 KEY FUNCTION DESCRIPTION	9
6 LCD DISPLAY	10
6.1 MAIN SCREEN.....	10
6.2 STATUS DESCRIPTION	11
6.1 MAIN MENU	15
7 START/STOP OPERATION	16
7.1 MANUAL START/STOP.....	16
7.2 AUTO START/STOP	17
8 PARAMETERS CONFIGURATION.....	21
8.1 ILLUSTRATION	21
8.2 PARAMETERS TABLE	21
8.3 DIGITAL INPUT/OUTPUT FUNCTION DESCRIPTION.....	31
8.4 DEFINITE TIME DELAY AND INVERSE DEFINITE MINIMUM TIME SETTING	37
9 HISTORICAL RECORDS.....	38
10 BLACK BOX RECORDS.....	39
11 SWITCH OPERATION	40
11.1 MANUAL OPERATION	40
11.2 AUTOMATIC OPERATION	41
12 ATS POWER SUPPLY	42
13 NEL CONTROL.....	43
13.1 ILLUSTRATION	43
13.2 AUTO OPERATION.....	43
13.3 MANUAL OPERATION.....	43
14 COMMUNICATION CONFIGURATION	44
15 TERMINALS.....	45
16 TYPICAL WIRING DIAGRAM	49
17 INSTALLATION	51
18 TROUBLE SHOOTING	52

1 OVERVIEW

HAT833 Three Power ATS controller is intelligent tri-supply module with configurable function, automatic measurement, LCD display, and digital communication. It combines digitization, intelligence and networking. Automatic measurement and control can reduce incorrect operation, which is an ideal option for ATS.

The powerful Microprocessor contained within the unit allows for precision voltage (3-way 3-phase) measuring and make accurate judgment and the corresponding volt free digital output port will active when there is over/under voltage, over/under frequency, loss of phase, phase sequence wrong and other abnormal condition occurs. It has compact structure, advanced circuits, simple wiring and high reliability, and can be widely used in electrical automatic control system of electric power, telecommunications, petroleum, coal, metallurgy, railways, municipal administration, intelligent building, etc.

SmartGen

2 PERFORMANCE AND CHARACTERISTICS

- System type can set as: Mains-Mains-Gen, Mains-Mains-Mains, Mains-Gen-Mains, etc;
- 4.3 inchs solid color 240x128 LCD display with white backlight, multilingual interface (including English, Simplified Chinese or other languages), push-button operation;
- Collect and display 3-way 3-phase voltage, frequency and phase sequence;
- Collect and display load active power, reactive power, apparent power, power factor and current;
- S1/S2/S3 separated over current warning/ trip alarm;
- NEL (Non-essential Load) trip function;
- Display S1/S2/S3 total kW energy, total kvar energy, total close times;
- Display continuous power supply time and S1/S2/S3 total power supply time;
- For Stored-Energy type ATS, its close relay will active after the PF Input is active;
- Over/under voltage, over/under frequency, over current, loss of phase, phase sequence wrong protection;
- Automatic/Manual mode. In manual mode, can force the switch to close or open;
- All parameters can be set on site. Passwords authentication ensures authorized staff operation only;
- The genset can be manual test on site to achieve start/stop operation;
- Automatic re-closing;
- Closing output signal can be set as on intervals or as continuous output;
- Applicable for 3 isolated neutral line;
- Real-time clock (RTC); event log function (event log can record 200 items circularly);
- Scheduled routing run & scheduled not run (can be set as start genset once a day/week/month whether with load or not);
- Can control two generators to work as cycle run mode, master run mode and balance run mode;
- Widely DC power supply range allows the controller can bear instantaneous 80V DC input;
- Large terminal space allows the controller can bear maximum 625V AC voltage input;
- With Dual-RS485 isolated communication interface. With "remote controlling, remote measuring, remote communication, remote regulating" function by the ModBus-RTU communication protocol. Can remote start/stop the genset and remote control the breaker to close or open;
- Suitable for various AC systems (3-phase 4-wire, 3-phase 3-wire, single-phase 2-wire, and 2-phase 3-wire);
- Modular design, self extinguishing ABS plastic shell, pluggable terminal, built-in mounting, compact structure with easy installation.

3 SPECIFICATION

Table 2 – Performance Parameters

Items	Contents	
Operating Voltage	1. DC8.0V~35.0V, continuous power supply 2. AC(90~305)V power supply A1N1/A2N2/A3N3	
Power Consumption	<7W(Standby mode:≤2W)	
AC Voltage Input	AC system	
	3P4W (L-L)	(80~530)V
	3P3W (L-L)	(80~625)V DC supply
	1P2W (L-N)	(50~305)V
	2P3W (A-B)	(80~530)V
Rated Frequency	50/60Hz	
Programmable Output 1~6 Relay Capacity	16A AC250V Volts free output	
Programmable Output 7~12 Relay Capacity	8A AC250V Volts free output	
Digital Input	GND (B-) connect is active.	
Communication	1. Dual-RS485 isolated interface, MODBUS Protocol 2. D-type USB port	
Case Dimensions	260mmx180mmx54mm	
Panel Cutout	242mmx161mm	
Working Conditions	Temperature: (-25~+70)°C; Relative Humidity: (20~93)%RH	
Storage Condition	Temperature: (-25~+70)°C	
Protection Level	IP65: when water proof gasket ring inserted between panel and housing.	
Insulation Strength	Apply AC1.5kV voltage between high voltage terminal and low voltage terminal; The leakage current is not more than 3mA within 1min.	
Weight	1.2kg	

4 MEASURE AND DISPLAY DATA

Table 3 – Display Parameters

No.	Measure & Display Data Items
1	S1/S2/S3 Power Phase Voltage
2	S1/S2/S3 Power Line Voltage
3	S1/S2/S3 Power Phase
4	S1/S2/S3 Power Frequency
5	Load 3-Phase Current
6	Load 3-Phase Active Power kW
7	Load Total Active Power kW
8	Load 3-Phase Reactive Power kvar
9	Load Total Reactive Power kvar
10	Load 3-Phase Apparent Power kVA
11	Load Total Apparent Power kVA
12	Load 3-Phase Power Factor PF
13	Load Average Power Factor PF
14	Continuous Power Supply Time (Currently)
15	Continuous Power Supply Time (Last Time)
16	S1 Total Power Supply Time
17	S2 Total Power Supply Time
18	S3 Total Power Supply Time
19	S1 Total kW Energy kWh
20	S2 Total kW Energy kWh
21	S3 Total kW Energy kWh
22	S1 Total kvar Energy kvarh
23	S2 Total kvar Energy kvarh
24	S3 Total kvar Energy kvarh
25	QS1 Total Close Times
26	QS2 Total Close Times
27	QS3 Total Close Times
28	Input/Output Port Status
29	Real Time Clock
30	Historical Records
31	Black Box Records
32	Communication Status

5 OPERATION




Fig.1 – Penal Indication Drawing

5.1 INDICATORS

Table 4 – Indicators Description

Indicator Type	Description
Alarm	Slow flashing (1time per sec) when warn alarm occurs. Fast flashing (5 times per sec) when fault alarm occurs.
Man	Light on when the module is in Manual mode.
Auto	Light on when the module is in Auto mode.
Alarm Mute	Light on when alarm mute.
IOO	Illuminated: QS1 closed, S1 supply power for load. Flashing: status switching
OIO	Illuminated: QS2 closed, S2 supply power for load. Flashing: status switching
OOI	Illuminated: QS3 closed, S3 supply power for load. Flashing: status switching
OOO	Illuminated: QS1, QS2, QS3 all open, offload. Flashing: status switching
Genset	Light on when the Start signal is be initiated.

5.2 KEY FUNCTION DESCRIPTION

Table 5 – Buttons Function Description

Icon	Buttons	Function Description
	IOO	Active in Manual mode. QS1 close and S1 supply after pressing this key.
	OIO	Active in Manual mode. QS2 close and S2 supply after pressing this key.
	OOI	Active in Manual mode. QS3 close and S3 supply after pressing this key.
	OOO	Active in Manual mode. Offload after pressing this key.
	Genset	Press this key to enter to genset manual start/stop operation interface.
	Alarm Mute	Mute the alarm.
	Man/Auto	Manual mode and Auto mode switching.
	Alarm Reset	Pressing this key can reset fault alarm.
	Return/Homepage	When setting parameters, press the key to return back. In main screen, press the key to return the first screen; in other screen, press the key to return to main screen.
	Set/Confirm	In main screen, press the key to enter to menu. In menu screen, press this key can move cursor and confirm setting information.
	Up	In main screen, press the key to scroll up screen. In menu interface, press this key to up cursor or increase value in setting menu.
	Down/Lamp Test	In main screen, press the key to scroll down screen. In menu interface, press this key to down cursor or decrease value in setting menu. In main screen, press the key for seconds to enter lamp test mode, LCD backlit and all LED lamps are lit and LCD screen display black.

6 LCD DISPLAY

6.1 MAIN SCREEN

Table 6 – Screen Display

Items	Display Contents
Homepage	S1 status, S2 status, S3 status, switch status; Supply system diagram, QS1 is switch for S1, QS2 is switch for S2, QS3 is switch for S3; S1/S2/S3 voltage and frequency; S1/S2/S3 priority switch; AutoTrans/Restore status
S1 S2 S3	S1 line voltage, phase voltage and frequency, phase angle, S1 total supply time. S2 line voltage, phase voltage and frequency, phase angle, S2 total supply time. S3 line voltage, phase voltage and frequency, phase angle, S3 total supply time. Start Status
Load 	3-phase current (I1,I2,I3); 3-Phase Active Power kW (P1,P2,P3); 3-Phase Reactive Power (Q1,Q2,Q3); 3-Phase Apparent Power kVA(S1,S2,S3); Total Active Power kW (sum of P1,P2,P3); Total Reactive Power kvar (sum of Q1,Q2,Q3); Total Apparent Power kVA(sum of S1,S2,S3); 3-Phase Power Factor PF(PF1,PF2,PF3); Average Power Factor PF(average of PF1,PF2,PF3)
Load 	Continuous Power Supply Time (currently); Continuous Power Supply Time (Last Time); S1 Total kW Energy; S2 Total kW Energy; S3 Total kW Energy; S1 Total kvar Energy; S2 Total kvar Energy; S3 Total kvar Energy;
QF 	QS1 Total Close Times; QS2 Total Close Times; QS3 Total Close Times;
I/O	Programmable digital input status and auxiliary status;

Items	Display Contents
	Programmable digital output status.
Comm. 	RS485-1 Comm. Status and Baud Rate; RS485-2 Comm. Status and Baud Rate; USB Comm. Status
Alarms 	Present alarm informations (Warn Alarm and Fault Alarm)
Status	Alarm status/working status; Real-time clock; Statusline is showed below in every main screen pages.

6.2 STATUS DESCRIPTION

Table 7 – S1 Voltage Status

No.	Item	Description
1	S1 Available	S1 Normal Delay
2	S1 Unavailable	S1 Abnormal Delay
3	S1 Available	Power supply voltage is within the setting range
4	S1 Blackout	Voltage is 0
5	S1 Over Volt	Voltage is higher than the set value
6	S1 Under Volt	Voltage has fallen below the set value
7	S1 Over Freq	Frequency is higher than the set value
8	S1 Under Freq	Frequency has fallen below the set value
9	S1 Loss of Phase	Loss of any phase of A, B and C
10	S1 Phase Seq Wrong	A-B-C phase sequence is wrong

Table 8 – S2 Voltage Status

No.	Item	Description
1	S2 Available	S2 Normal Delay
2	S2 Unavailable	S2 Abnormal Delay
3	S2 Available	Power supply voltage is within the setting range.
4	S2 Blackout	Voltage is 0.
5	S2 Over Volt	Voltage is higher than the set value.
6	S2 Under Volt	Voltage has fallen below the set value.
7	S2 Over Freq	Frequency is higher than the set value.
8	S2 Under Freq	Frequency has fallen below the set value.
9	S2 Loss of Phase	Loss of any phase of A, B and C.
10	S2 Phase Seq Wrong	A-B-C phase sequence is wrong.



Table 9 – S3 Voltage Status

No.	Item	Description
1	S3 Available	S3 Normal Delay
2	S3 Unavailable	S3 Abnormal Delay
3	S3 Available	Power supply voltage is within the setting range.
4	S3 Blackout	Voltage is 0.
5	S3 Over Volt	Voltage is higher than the set value.
6	S3 Under Volt	Voltage has fallen below the set value.
7	S3 Over Freq	Frequency is higher than the set value.
8	S3 Under Freq	Frequency has fallen below the set value.
9	S3 Loss of Phase	Loss of any phase of A, B and C.
10	S3 Phase Seq Wrong	A-B-C phase sequence is wrong.

Table 10 – Genset Status

No.	Item	Description
1	Genset Start Delay	Delay time before genset start
2	Genset Return Delay	Delay time before genset stop
3	Scheduled Not Work	When scheduled not run is active, its duration time will be displayed.
4	Scheduled Work	When scheduled run is active, its duration time will be displayed.
5	S1 Cycle Run	S1 cycle run countdown will be terminated when cycle start is active.
6	S2 Cycle Run	S2 cycle run countdown will be terminated when cycle start is active.
7	S3 Cycle Run	S3 cycle run countdown will be terminated when cycle start is active.
8	S1 Genset Working	Active only when system has 2 gensets and S1 generating.
9	S2 Genset Working	Active only when system has 2 gensets and S2 generating.
10	S3 Genset Working	Active only when system has 2 gensets and S3 generating.
11	Genset Working	Genset start signal output.
12	Genset Standby	There is no start genset signal output.

Table 11 – Switch Status

No.	Item	Description
1	Ready to Transfer	Switch transfer begins.
2	QS1 Closing	QS1 closing delay is in progress.
3	QS1 Opening	QS1 opening delay is in progress.
4	QS2 Closing	QS2 closing delay is in progress.
5	QS2 Opening	QS2 opening delay is in progress.
6	QS3 Closing	QS3 closing delay is in progress.
7	QS3 Opening	QS3 opening delay is in progress.
8	Transfer Rest	Interval time between switch transfer
9	Closing QS1 Again	If “Closing Again Delay” is not 0, when the QS1 “Fail to open” condition occurs, it’s the delay time before the close relay is active for the second



No.	Item	Description
		time.
10	Opening QS1 Again	If “Opening Again Delay” is not 0, when the QS1 “Fail to close” condition occurs, it’s the delay time before the close relay is active for the second time.
11	Closing QS2 Again	If “Closing Again Delay” is not 0, when the QS2 “Fail to open” condition occurs, it’s the delay time before the close relay is active for the second time.
12	Opening QS2 Again	If “Opening Again Delay” is not 0, when the QS2 “Fail to close” condition occurs, it’s the delay time before the close relay is active for the second time.
13	Closing QS3 Again	If “Closing Again Delay” is not 0, when the QS3 “Fail to open” condition occurs, it’s the delay time before the close relay is active for the second time.
14	Opening QS3 Again	If “Opening Again Delay” is not 0, when the QS3 “Fail to close” condition occurs, it’s the delay time before the close relay is active for the second time.
15	Waiting QS1 PF	Before QS1 is closed, it’s the delay time to confirm “QS1 PF Input” signal is active.
16	Waiting QS2 PF	Before QS2 is closed, it’s the delay time to confirm “QS2 PF Input” signal is active.
17	Waiting QS3 PF	Before QS3 is closed, it’s the delay time to confirm “QS3 PF Input” signal is active.
18	Elevator Delay	Elevator control output before ATS transfer.
19	S1 On Load	QS1 was already closed and S1 is taking load.
20	S2 On Load	QS2 was already closed and S2 is taking load.
21	S3 On Load	QS3 was already closed and S3 is taking load.
22	Offload	Switch was already opened and load is disconnected.

Warning alarms are active when controller detects the alarm signals, and alarm indicator will flash slowly (1time per sec). When alarm is reset, indicator is extinguished, which means warn alarms are not latched.

Table 12 – Warning Alarms

No.	Item	Description
1	S1 Over Current Warn	When the S1 current has exceeded the pre-set value and the action select “Warn”, it will initiate a warning alarm.
2	S2 Over Current Warn	When the S2 current has exceeded the pre-set value and the action select “Warn”, it will initiate a warning alarm.
3	S3 Over Current Warn	When the S3 current has exceeded the pre-set value and the action select “Warn”, it will initiate a warning alarm.
4	Forced Open Warn	When the input is active and the action (cut off non-fire supply) select



No.	Item	Description
		“Warn”, it will initiate a warning alarm.
5	Battery Under Volt	When the battery voltage has fallen below the pre-set value, it will initiate a warning alarm.
6	Battery Over Volt	When the battery voltage has exceeded the pre-set value, it will initiate a warning alarm.

Fault alarms are active when controller detects the alarm signals. Alarm indicator will flash rapidly (5 times per sec) and the alarm will last until it was removed manually. Fault alarms are latched.

Table 13 – Fault Aalrms

No.	Item	Description
1	QS1 Failed to Close	QS1 fail to close.
2	QS1 Failed to Open	QS1 fail to open.
3	QS2 Failed to Close	QS2 fail to close.
4	QS2 Failed to Open	QS2 fail to open.
5	QS3 Failed to Close	QS3 fail to close.
6	QS3 Failed to Open	QS3 fail to open.
7	S1 Over Current Trip	When the S1 is taking load and its current has exceeded the pre-set value, and the action select “Trip”, it will initiate a trip alarm.
8	S2 Over Current Trip	When the S2 is taking load and its current has exceeded the pre-set value and the action select “Trip”, it will initiate a trip alarm.
9	S3 Over Current Trip	When the S3 is taking load and its current has exceeded the pre-set value and the action select “Trip”, it will initiate a trip alarm.
10	Forced Open Fault	When the input is active and the action (cut off non-fire supply) select “Fault”, it will initiate a fault alarm.
11	S1 Genset Fault	Only when system has 2 gensets and S1 generating, S1 fail to start.
12	S2 Genset Fault	Only when system has 2 gensets and S2 generating, S2 fail to start.
13	S3 Genset Fault	Only when system has 2 gensets and S3 generating, S3 fail to start.
14	Switch Trip Alarm	It will initiate a fault alarm, when the input is active.

The indication information will continuously display for 2s after it is active.

Table 14 – Indication Information

No.	Item	Description
1	Please Reset The Alarm	When there is fault alarm occurs, the indication will be displayed when change the genset mode to Auto Mode manually.
2	S1 Already Closed.	After S1 was already closed, the indication will be displayed when “S1 close (IOO)” button is pressed.
3	S2 Already Closed.	After S2 was already closed, the indication will be displayed when “S2 close (OIO)” button is pressed.



No.	Item	Description
4	S3 Already Closed.	After S3 was already closed, the indication will be displayed when “S3 close (OOI)” button is pressed.
5	Panel Locked	The information displays when panel lock is active and keys are pressed (Manual/Auto, IOO, OIO, OOI, OOO and Test keys).

Table 15 – Other Status Information

No.	Item	Description
1	Start Inhibit	Genset start Inhibit is active.
2	S1 Load Inhibit	S1 Load Inhibit input is active.
3	S2 Load Inhibit	S2 Load Inhibit input is active.
4	S3 Load Inhibit	S3 Load Inhibit input is active.
5	NEL 1 Trip	NEL1 off load signal is output.
6	NEL2 Trip	NEL2 off load signal is output.
7	NEL3 Trip	NEL3 off load signal is output.
8	Remote Gen On Load	Remote start (on load) signal is active.
9	Remote Gen Off Load	Remote start (off load) signal is active.
10	Gen Start Mains NG	Start genset when mains is abnormal.
11	Gen Start Master	Start when the gens supply and switching to highest priority.
12	Auto Mode	Current mode is Auto mode.
13	Manual Mode	Current mode is Manual mode.

6.1 MAIN MENU

In main screen, press  key will enter into the menu interface.

<ul style="list-style-type: none"> 1. Configuration 2. Data Calibration 3. Historical Records 4. Black Box Records 5. AutoCharge/Recover 6. Language 7. About 	<p>Press Up/Down key to choose parameters (the current line was highlighted with black) and then press Confirm key to enter into the corresponding display screen.</p>
--	--

NOTE: Default password is 01234, user can change it in case of others change the parameters setting.

Please clearly remember the password after changing. If you forget it, please contact SmartGen services.

NOTE: Data Calibration is for factory use only and correct passwords must be input before entered.

7 START/STOP OPERATION

7.1 MANUAL START/STOP

7.1.1 PANEL START/STOP

In the main screen, press  key to enter to “Manual Test Genset” interface when system type is “S1 Mains S2 Gens S3 Mains, S1 Gens S2 Mains S3 Mains, S1 Mains S2 Mains S3 Gens”.

Manual Test Genset	Press “Up/Down” key to choose parameters (the current line was highlighted with black) and then press “Confirm” key to confirm.
Return	
Genset Stop	
Genset Start	

Genset Stop: Disconnect the start signal, i.e. stop the running genset.

Genset Start: Output the start signal, i.e. start the genset.

When system is “S1 Gens S2 Gens S3 Mains”, manual start/stop menu interface is as follows:

Manual Test Genset	Press “Up/Down” key to choose parameters (the current line was highlighted with black) and then press “Confirm” key to confirm.
Return	
S1 Genset Stop	
S1 Genset Start	
S2 Genset Stop	
S2 Genset Start	

S1 Genset Stop: Disconnect the S1 start signal, i.e. stop the running S1 genset.

S1 Genset Start: Output the S1 start signal, i.e. start the S1 genset.

S2 Genset Stop: Disconnect the S2 start signal, i.e. stop the running S2 genset.

S2 Genset Start: Output the S2 start signal, i.e. start the S2 genset.

When system is “S1 Gens S2 Mains S3 Gens”, manual start/stop menu interface is as follows:

Manual Test Genset	Press “Up/Down” key to choose parameters (the current line was highlighted with black) and then press “Confirm” key to confirm.
Return	
S1 Genset Stop	
S1 Genset Start	
S3 Genset Stop	
S3 Genset Start	

S1 Genset Stop: Disconnect the S1 start signal, i.e. stop the running S1 genset.

S1 Genset Start: Output the S1 start signal, i.e. start the S1 genset.

S3 Genset Stop: Disconnect the S3 start signal, i.e. stop the running S3 genset.

S3 Genset Start: Output the S3 start signal, i.e. start the S3 genset.

When system is “S1 Mains S2 Gens S3 Gens”, manual start/stop menu interface is as follows:

Manual Test Genset	Press Up/Down key to choose parameters (the current line was highlighted with black) and then press Confirm key to confirm.
Return	
S2 Genset Stop	
S2 Genset Start	
S3 Genset Stop	
S3 Genset Start	

S2 Genset Stop: Disconnect the S2 start signal, i.e. stop the running S2 genset.

S2 Genset Start: Output the S2 start signal, i.e. start the S2 genset.

S3 Genset Stop: Disconnect the S3 start signal, i.e. stop the running S3 genset.

S3 Genset Start: Output the S3 start signal, i.e. start the S3 genset.

7.1.2 REMOTE START/STOP

Send remote start/stop signals using MODBUS protocol via RS485 port.

Remote Stop: Disconnect the start signal, i.e. stop the running genset.

Remote Start: Output the start signal, i.e. start the genset.

7.2 AUTO START/STOP

7.2.1 START CONDITIONS

7.2.1.1 INPUT START

Set input port as “Remote Start On Load” or “Remote Start Off Load”, both could not be set simultaneously.

Remote Start on Load: When the input is active, genset close relay will active after genset is normal; when the input inactive, genset will stop automatically.

Remote Start off Load: When the input is active, mains close relay will active after mains is normal; when the input inactive, genset will stop automatically.

7.2.1.2 Gen Start Mains NG

When mains is abnormal and the input is active, gens close relay will active after gens is normal.

7.2.1.3 Gen Start Master

This input is active when generator has master priority.

7.2.2 GEN-GEN START/STOP

When system is “S1 Gens S2 Gens S3 Mains, S1 Gens S2 Mains S3 Gens, S1 Mains S2 Gens S3 Gens”, input port start/stop function is as follows:

When system is “S1 Gens S2 Gens S3 Mains”, S1 S2 start/stop; when system is “S1 Gens S2 Mains S3 Gens”, S1 S3 start/stop; when system is “S1 Mains S2 Gens S3 Gens”, S2 S3 start/stop.

Gen Start Mains NG: when mains is abnormal, S1 or S2 or S3 (determined by start priority) start to supply. Genset close relay will active after genset is normal.

Remote Start on Load: Detect S1 or S2 or S3 start output according to start priority and start mode. Genset close relay will active after genset is normal.

Remote Start off Load: Detect S1 or S2 or S3 start output according to start priority and start mode. Both genset S1 close relay and S2 close relay are deactivated after genset start.

Start Mode: Cycle Run Start, Master Run Start, Balance Run Start.

Cycle Run Start:

If system is “S1 Gens S2 Gens S3 Mains”, when S3 Mains is abnormal or remote start is active, S1 and S2 cycle run start according to the cycle run time. At the first time to start the genset, choose “S1 Start” or “S2 Start” depends on “Priority”. e.g. S1 start firstly if “S1” has higher priority. Then S1 cycle run countdown is started according to the preset delay. At the same time, genset fault delay will be initiated. If S1 genset is normal before the fault delay has expired, S1 will take load; S2 start after the preset S1 cycle run delay has expired and the S2 loading process is same as S1. S1 will stop automatically after the S2 has take load successfully. S1 and S2 will cycle run in this way alternately until the remote start signal deactivated.

During the start process, if there is genset fault alarm (genset fault delay overtime or genset fault input is active), fail to close or load inhibit alarm occurs, the starting genset will be stop immediately and the additional genset will be start automatically.

During the cycle run process, if “Auto Mode” is selected, the current status will be hold and the “cycle run countdown” will be suspended.

Master-Slave Gens

Master genset will be start when mains abnormal or remote start signal is active. During the start process, if there is genset fault alarm (genset supply delay overtime or genset fault input is active), fail to close or load inhibit alarm occurs, the starting genset will be stop immediately and the additional genset will be start automatically. Otherwise, the master run genset will running continuously until the remote start signal deactivated or mains normal.

Balance Run

The gensets which has the shortest running hours will be start when mains abnormal or remote start signal is active. During the start process, if there is genset fault alarm (genset supply delay overtime or genset fault input is active), fail to close or load inhibit alarm occurs, the starting genset will be stop immediately and the additional genset will be start automatically. Otherwise, the current genset will running continuously until the remote start signal deactivated.

In system of 2 sets of gensets to start/stop genset should meet following several conditions:

- 1) It is active in Auto mode;
- 2) System set as “S1 Gens S2 Gens S3 Mains” or “S1 Gens S2 Mains S3 Gens” or “S1 Mains S2 Gens S3 Gens”;
- 3) If system is “S1 Gens S2 Gens S3 Mains”, the output should be set as “S1 Genset Start” and “S2 Genset Start”; if system is “S1 Gens S2 Mains S3 Gens”, the output should be set as “S1 Genset Start” and “S3 Genset Start”; if system is “S1 Mains S2 Gens S3 Gens”, the output should be set as “S2 Genset Start” and “S3 Genset Start”;
- 4) If system is “S1 Gens S2 Gens S3 Mains”, the input should be set as “S1 Genset Fault Input”, “S2 Genset Fault Input” and “Remote StartOnLoad” or “Remote StartOffLoad”; if system is “S1 Gens S2 Mains S3 Gens”, the input should be set as “S1 Genset Fault Input”, “S3 Genset Fault Input” and “Remote StartOnLoad” or “Remote StartOffLoad”; if system is “S1 Mains S2 Gens S3 Gens”, the input should be set as “S2 Genset Fault Input”, “S3 Genset Fault Input” and “Remote StartOnLoad” or “Remote StartOffLoad”;
- 5) Should set the system as “Gen-Gen Start Mode”;
- 6) Should configure setting “Genset Supply Delay”, If start mode is cycle run, also should set “S1 Cycs Work Time”, “S2 Cycs Work Time” or “S1 Cycs Work Time”, “S3 Cycs Work Time” or “S2 Cycs Work Time”, and “S3 Cycs Work Time”;

Among input ports, “S1 Genset Fault Input”, “S2 Genset Fault Input” and “S3 Genset Fault Input” are selective setting, Genset fault can be judged by “Genset Supply Delay” and there no need to inquire the fault alarm via input port.

When Gen-Gen start type configured as “Not Used”, there is no start genset signals output.

For example:

Table 16 – Genset Start

System Type	Start Conditions	Result
S1 Gens S2 Gens S3 Mains	Input Active (Remote StartOnLoad/ Remote StartOffLoad)	S1 Genset Start Output
	S3 Abnormal	
	Priority: S1>S2>S3	

7.2.3 SCHEDULED RUN

Once “Scheduled Run” enables, users can set the scheduled start time. Controller will send start signal at preset start time. Start signal will deactivated after the start delay has expired.

“Scheduled Run On Load” or “Scheduled Run Off Load” can be set.

Scheduled Run On Load: When the input is active, genset close relay will active after genset is normal.

Scheduled Run Off Load: When the input is active, mains close relay will active after mains is normal.

Cycle time of *Scheduled Run* can be set as start monthly, weekly and daily.

Run Monthly: Which month to start, start date and time can be set.

Run Weekly: Can start the genset at the same time in couple days of a week. Eg. Start the genset at 8:00 a.m. from Monday to Friday and keep 10 hours.

Run Daily: Can start the genset at same time everyday.

7.2.4 SCHEDULED NOT RUN

Once "Scheduled Not Run" enables, users can set the "Scheduled Not Start" time. Start signal will deactivated at preset time and it will be inhibited before the delay has expired.

Cycle time of "Scheduled Not Run" can be set as monthly, weekly and daily.

Not Run Monthly: Which month *not* start, *not* start date and time can be set.

Not Run Weekly: Can not start the genset at the same time in couple days of a week. Eg. Not Start the genset at 19:00 p.m. from Monday to Friday and keep 12 hours.

Not Run Daily: Can not start the genset at same time everyday.

 **Note:** "Scheduled Not Run" operation is prior to "Scheduled Run" operation.

SmartGen

8 PARAMETERS CONFIGURATION

8.1 ILLUSTRATION

In the main interface, press /OK key, choose **Configuration** and press /OK again to enter into password confirmation interface. If password is correct, enter into parameter setting interface, otherwise, exit to main interface directly. Factory default password is **01234**. In parameters configuration interface, pressing  key to return the prior menu.

8.2 PARAMETERS TABLE

Table 17 – Parameter Configuration Form

No.	Item	Range	Default	Description
AC Config				
1	S1 Volt Normal	(0-3600) s	10	The delay from S1 voltage abnormal to normal.
2	S1 Volt Abnormal	(0-3600)s	5	The delay from S1 voltage normal to abnormal.
3	S2 Volt Normal	(0-3600)s	10	The delay from S2 voltage abnormal to normal.
4	S2 Volt Abnormal	(0-3600)s	5	The delay from S2 voltage normal to abnormal.
5	S3 Volt Normal	(0-3600)s	10	The delay from S3 voltage abnormal to normal.
6	S3 Volt Abnormal	(0-3600)s	5	The delay from S3 voltage normal to abnormal.
7	Master Set	(0~5)	0	0: S1>S2>S3 1: S2>S1>S3 2: S3>S1>S2 3: S1>S3>S2 4: S2>S3>S1 5: S3>S2>S1
8	System Type	(0~6)	6	0: S1M S2G S3M 1: S1G S2M S3M 2: S1M S2M S3M 3: S1G S2G S3M 4: S1M S2G S3G 5: S1G S2M S3G 6: S1M S2M S3G
9	AC System	(0~3)	0	0: 3 Phase,4 Wire (3P4W) 1: 3 Phase,3 Wire (3P3W)



No.	Item	Range	Default	Description
				2: 2 Phase,3 Wire (2P3W) 3: Single Phase,2 Wire (1P2W)
10	PT Fitted	(0-1)	0	0: Disable ; 1: Enable
11	PT Primary	(30-30000)V	100	Primary voltage of voltage transformer
12	PT Secondary	(30-1000)V	100	Secondary voltage of voltage transformer
13	Rated Voltage	(0-30000)V	220	Rated voltage of AC system
14	Over Volt Warn	(0-1)	1	0: Disable ; 1: Enable
15	Set Value	(0-200)%	120	Upper limit value of voltage; it is abnormal if the value has exceeded the set value.
16	Return	(0-200)%	115	Upper limit return value of voltage; it is normal only when the value has fallen below the set value.
17	Under voltage Warn	(0-1)	1	0: Disable ; 1: Enable
18	Set Value	(0-200)%	80	Lower limit value of voltage; it is abnormal if the value has fallen below the set value.
19	Return Value	(0-200)%	85	Lower limit return value of voltage; it is normal only when the value has exceeded the set value.
20	Rated Frequency	(10.0-75.0)Hz	50.0	Rated frequency of AC system
21	Over Frequency Warn	(0-1)	1	0: Disable ; 1: Enable
22	Set Value	(0-200)%	110	Upper limit value of frequency; it is abnormal if the value has exceeded the set value.
23	Return Value	(0-200)%	104	Upper limit return value of frequency; it is normal only when the value has fallen below the set value.
24	Under Frequency Warn	(0-1)	1	0: Disable ; 1: Enable
25	Set Value	(0-200)%	90	Lower limit value of frequency; it is abnormal if the value has fallen below the set value.
26	Return Value	(0-200)%	96	Lower limit return value of frequency; it is normal only when the value has exceeded the set value.
27	Phase Sequence Wrong	(0-1)	1	0: Disable ; 1: Enable
Switch				
1	Fixed Close/Open Time	(0-1)	0	0: Disable ; 1: Enable Disable: The output time was judged depends on the close relay; the longest output time up to the set delay. Enable: The output time last for the preset time.
2	Close Delay	(0.1-20.0)s	5.0	Pulse time of close relay.



No.	Item	Range	Default	Description
3	Open Delay	(0.1-20.0)s	5.0	Pulse time of open relay.
4	Transfer Interval	(0-9999)s	1	Interval time from S1 switch open to S2 switch close; or from S2 switch open to S1 switch close.
5	Auto Charge/Recover	(0-1)	1	0: Auto Charge Man Rec. 1: Auto Charge/Rec.
6	Again Close Delay	(0-20.0)s	0.0	When the breaker fail to open for the first time, then the module will close for the second time and the Again Close Delay begins, after the delay has expired, if still failed to open for the second time, the module will send out fail to open alarm.
7	Again Open Delay	(0-20.0)s	0.0	When the breaker fail to close for the first time, then the module will open for the second time and the Again Open Delay begins, after the delay has expired, if still failed to close for the second time, the module will send out fail to close alarm.
8	Forced Open Action	(0-1)	0	0: Warn Alarm 1: Fault Alarm
9	Continually Close	(0-1)	0	0: Disable ; 1: Enable If "Enable" is selected, "Close Time" and "Open Time" are deactivated.
10	Switch Power Type	(0~1)	1	0: DC Supply; 1: AC Supply
11	AC Volt Lower Limit	(0~100)%	70	Lower limit voltage of switch power; The switch cannot transfer when the value has fallen below the set value.
12	AC Volt Upper Limit	(0~200)%	200	Upper limit voltage of switch power; The switch cannot transfer when the value has exceeded the set value.
Generator				
1	Start Delay	(0-9999)s	1	When the genset is ready to start, start delay begins, after the start delay has expired, start signal will be initiated.
2	Stop Delay	(0-9999)s	5	When the genset is ready to stop, stop delay begins, after the stop delay has expired, stop signal will be initiated.
3	Gen-Gen Start Mode	(0~3)	0	0: Cycs Run 1: Master Run 2: Balance Run 3: Not Used
4	S1 Cycle Running Time	(0-9999)min	720	Gens cycle start S1 running time.
5	S2 Cycle RunningTime	(0-9999)min	720	Gens cycle start S2 running time.



No.	Item	Range	Default	Description
6	S3 Cycle RunningTime	(0-9999)min	720	Gens cycle start S3 running time.
7	Supply Delay	(0-9999)s	120	When the start signal is active, the start delay will be initiated. If the gen voltage lasts abnormal after the delay has expired, "Genset Fault" alarm will be initiated.
8	Battery Volt	(0-1)	0	0: Disable ; 1: Enable
9	Battery Under Volt Warn	(0-1)	0	0: Disable ; 1: Enable
10	Set Value	(0-100.0)V	10.0	"Battery Under Volts" alarm will be initiated if the battery voltage has fallen below the set value.
11	Return Value	(0-100.0)V	10.5	"Battery Under Volts" alarm will be removed if the battery voltage has exceeded the set value.
12	Battery Over Volt Warn	(0-1)	0	0: Disable ; 1: Enable
13	Set Value	(0-100.0)V	30.0	"Battery Over Volts" alarm will be initiated if the battery voltage has exceeded the set value.
14	Return Value	(0-100.0)V	29.5	"Battery Over Volts" alarm will be removed if the battery voltage has fallen below the set value.
Scheduler				
1	Schedule Run	(0-1)	0	0: Disable ; 1: Enable
2	Run Mode	(0-1)	0	0: Off Load 1: On Load
3	Cycle Selection	(0-2)	0	0: Monthly 1: Weekly 2: Daily
4	Time (Month)	(1~4095)	4095	Bit0: Jan. Bit1: Feb. Bit2: Mar. Bit3: Apr. Bit4: May Bit5: June Bit6: July Bit7: Aug. Bit8: Sep. Bit9: Oct. Bit10: Nov. Bit11: Dec.



No.	Item	Range	Default	Description
5	Time (Day)	(1~31)	1	The date of start the genset
6	Time (Week)	(1-127)	1	Bit0: Sunday Bit1: Monday Bit2: Tuesday Bit3: Wednesday Bit4: Thursday Bit5: Friday Bit6: Saturday
7	Time (Hour)	(0-23)h	0	The time of start the genset
8	Time (Minute)	(0-59)min	0	
9	Duration	(0-30000)min	30	The duration time of genset running
10	Scheduled Not Run	(0~1)	0	0: Disable 1: Enable
11	Run Mode	(0-2)	0	0: Monthly 1: Weekly 2: Daily
12	Time (Month)	(1~4095)	4095	Bit0: Jan. Bit1: Feb. Bit2: Mar. Bit3: Apr. Bit4: May Bit5: June Bit6: July Bit7: Aug. Bit8: Sep. Bit9: Oct. Bit10: Nov. Bit11: Dec.
13	Time (Day)	(1~31)	1	The date of <i>NOT</i> start the genset
14	Time (Week)	(1-127)	1	Bit0: Sunday Bit1: Monday Bit2: Tuesday Bit3: Wednesday Bit4: Thursday Bit5: Friday Bit6: Saturday
15	Time (Hour)	(0-23)	0	The time of <i>NOT</i> start the genset
16	Time (Minute)	(0-59)	0	
17	Duration	(0-30000)	30	The duration time of genset <i>NOT</i> running
Load				
1	Current CT Enable	(0-1)	1	0: Disable ; 1: Enable



No.	Item	Range	Default	Description
2	CT Primary/5	(5-6000)A	500	The primary current of CT.
3	S1 Full Load Rating	(5-6000)A	500	The current of S1 taking full load
4	S2 Full Load Rating	(5-6000)A	500	The current of S2 taking full load
5	S3 Full Load Rating	(5-6000)A	500	The current of S3 taking full load
6	S1 Max kW Rating	(1-20000)kW	200	The maximum active power of S1 taking load
7	S2 Max kW Rating	(1-20000)kW	200	The maximum active power of S2 taking load
8	S3 Max kW Rating	(1-20000)kW	200	The maximum active power of S3 taking load
9	Over Current Enable	(0-1)	1	0: Disable ; 1: Enable
10	Over Current	(0-200)%	120	Over current set value
11	Action	(0-1)	0	0: Warn 1: Trip
12	Type	(0-1)	0	0: Definite Time 1: IDMT(Inverse Definite MMinimum Time)
13	Delay	(0-3600)s	10	It's the over current delay time when "Definite Time" is selected.
14	Multiply	(1-36)	36	It's the over current multiply when "IDMT" is selected.
15	Elevator Enable	(0-1)	0	0: Disable ; 1: Enable
16	Elevator Delay	(0-300)s	300	It's the delay time before the load disconnect or switch transfer. Used for control the running elevator stop at the nearest floor until the switch transfer is terminated.
17	NEL Trip	(0-1)	0	0: Disable ; 1: Enable
18	NEL1 Set Value	(0-200)%	90	Off load output will active if the load power has exceeded the set value and the delay time has expired.
19	NEL1 Delay	(0-3600)s	5	
20	NEL2 Set Value	(0-200)%	100	Off load output will active if the load power has exceeded the set value and the delay time has expired.
21	NEL2 Delay	(0-3600)s	1	
22	NEL Return Enable	(0-1)	0	0: Disable ; 1: Enable
23	Set Value	(0-200)%	50	NEL control will deactivated if the load power has fallen below the set value and the delay time has expired.
24	Delay	(0-3600)s	5	
25	NEL Num	(1-3)	3	NEL number
26	Mains Load NEL Enable	(0-1)	0	0: Disable ; 1: Enable
Digit Inputs				
1	Digital Input 1	(0~47)	1	Forced Open
2	Active Type	(0~1)	0	0: Close to activate; 1: Open to activate



No.	Item	Range	Default	Description
3	Digital Input 2	(0~47)	8	Breaker Trip Input
4	Active Type	(0~1)	0	0: Close to activate; 1: Open to activate
5	Digital Input 3	(0~47)	0	Not Used
6	Active Type	(0~1)	0	0: Close to activate; 1: Open to activate
7	Digital Input 4	(0~47)	0	Not Used
8	Active Type	(0~1)	0	0: Close to activate; 1: Open to activate
9	Digital Input 5	(0~47)	0	Not Used
10	Active Type	(0~1)	0	0: Close to activate; 1: Open to activate
11	Digital Input 6	(0~47)	0	Not Used
12	Active Type	(0~1)	0	0: Close to activate; 1: Open to activate
13	Digital Input 7	(0~47)	0	Not Used
14	Active Type	(0~1)	0	0: Close to activate; 1: Open to activate
15	Digital Input 8	(0~47)	0	Not Used
16	Active Type	(0~1)	0	0: Close to activate; 1: Open to activate
Relay Outputs				
1	Relay Output 1	(0~1)	0	0: Output (NO) 1: Output (NC)
2	Contents Setting	(0~107)	34	QS1 Close Control
3	Relay Output 2	(0~1)	0	0: Output (NO) 1: Output (NC)
4	Contents Setting	(0~107)	35	QS1 Open Control
5	Relay Output 3	(0~1)	0	0: Output (NO) 1: Output (NC)
6	Contents Setting	(0~107)	36	QS2 Close Control
7	Relay Output 4	(0~1)	0	0: Output (NO) 1: Output (NC)
8	Contents Setting	(0~107)	37	QS2 Open Control
9	Relay Output 5	(0~1)	0	0: Output (NO) 1: Output (NC)
10	Contents Setting	(0~107)	38	QS3 Close Control
11	Relay Output 6	(0~1)	0	0: Output (NO) 1: Output (NC)
12	Contents Setting	(0~107)	39	QS3 Open Control
13	Relay Output 7	(0~1)	0	0: Output (NO) 1: Output (NC)



No.	Item	Range	Default	Description
14	Contents Setting	(0~107)	0	Not Uesd
15	Relay Output 8	(0~1)	0	0: Output (NO) 1: Output (NC)
16	Contents Setting	(0~107)	0	Not Uesd
17	Relay Output 9	(0~1)	0	0: Output (NO) 1: Output (NC)
18	Contents Setting	(0~107)	0	Not Uesd
19	Relay Output 10	(0~1)	0	0: Output (NO) 1: Output (NC)
20	Contents Setting	(0~107)	0	Not Uesd
21	Relay Output 11	(0~1)	1	0: Output (NO) 1: Output (NC)
22	Contents Setting	(0~107)	32	Genset start Output
23	Relay Output 12	(0~1)	0	0: Output (NO) 1: Output (NC)
24	Contents Setting	(0~107)	0	Not Uesd
25	Combined 1 Or Out 1 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
26	Combined 1 Or Out 1 Contents Setting	(0~107)	23	S1 Available
27	Combined 1 Or Out 2 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
28	Combined 1 Or Out 2 Contents Setting	(0~107)	25	S2 Available
29	Combined 1 And Out Active Type	(0~1)	1	0: Output (NO) 1: Output (NC)
30	Combined 1 And Out Contents Setting	(0~107)	0	Not Uesd
31	Combined 2 Or Out 1 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
32	Combined 2 Or Out 1 Contents Setting	(0~107)	0	Not Uesd
33	Combined 2 Or Out 2 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
34	Combined 2 Or Out 2 Contents Setting	(0~107)	0	Not Uesd
35	Combined 2 And Out Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
36	Combined 2 And Out Contents Setting	(0~107)	0	Not Uesd
37	Combined 3 Or Out 1 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
38	Combined 3 Or Out 1 Contents Setting	(0~107)	0	Not Uesd



No.	Item	Range	Default	Description
39	Combined 3 Or Out 2 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
40	Combined 3 Or Out 2 Contents Setting	(0~107)	0	Not Uesd
41	Combined 3 And Out Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
42	Combined 3 And Out Contents Setting	(0~107)	0	Not Uesd
43	Combined 4 Or Out 1 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
44	Combined 4 Or Out 1 Contents Setting	(0~107)	0	Not Uesd
45	Combined 4 Or Out 2 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
46	Combined 4 Or Out 2 Contents Setting	(0~107)	0	Not Uesd
47	Combined 4 And Out Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
48	Combined 4 And Out Contents Setting	(0~107)	0	Not Uesd
49	Combined 5 Or Out 1 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
50	Combined 5 Or Out 1 Contents Setting	(0~107)	0	Not Uesd
51	Combined 5 Or Out 2 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
52	Combined 5 Or Out 2 Contents Setting	(0~107)	0	Not Uesd
53	Combined 5 And Out Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
54	Combined 5 And Out Contents Setting	(0~107)	0	Not Uesd
55	Combined 6 Or Out 1 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
56	Combined 6 Or Out 1 Contents Setting	(0~107)	0	Not Uesd
57	Combined 6 Or Out 2 Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
58	Combined 6 Or Out 2 Contents Setting	(0~107)	0	Not Uesd
59	Combined 6 And Out Active Type	(0~1)	0	0: Output (NO) 1: Output (NC)
60	Combined 6 And Out Contents Setting	(0~107)	0	Not Uesd
Module Settings				



No.	Item	Range	Default	Description
1	Power On Mode	(0-2)	0	0: Last Mode (Keep the working mode last time running) 1: Manual 2: Auto
2	Language	(0~2)	0	0: Chinese 1: English 2: Other (Language can be set via PC software, Default: Traditional Chinese)
3	Password	(00000~65535)	01234	For entering parameters setting.
4	Module Address	(1~254)	1	RS485 communication address
5	RS485-1 Baud	(0~3)	2	0: 2400 1: 4800 2: 9600 3: 19200
6	RS485-1 Stop Bit	(1~2)	2	2 stop bits or 1 stop bit can be set.
7	RS485-2 Baud	(0~3)	2	0: 2400 1: 4800 2: 9600 3: 19200
8	RS485-2 Stop Bit	(1~2)	2	2 stop bits or 1 stop bit can be set.
9	Date and Time			
10	Controller Description 1	(0~20) characters		"About" information is displayed. Any characters can be inputted via PC software (letter occupies 1 character, Chinese character occupies 2.).
11	Controller Description 2	(0~20) characters		

8.3 DIGITAL INPUT/OUTPUT FUNCTION DESCRIPTION

8.3.1 INPUT PORTS FUNCTION

Table 18 – Input Ports Function Description

No.	Item	Description
0	Not Uesd	Invalid
1	Forced Open	No matter the genset is in manual mode or Auto mode, when the input is active, this will force the breaker to transfer the ATS to OFF position. “No Breaking” ATS is unavailable.
2	Remote StartOnLoad	When active, controller will send genset start signal immediately. When mains is normal, genset will close the breaker.
3	Remote StartOffLoad	When active, controller will send a genset start signal immediately. When mains is normal, genset will not close the breaker.
4	Lamp Test	When active, all LED lights on the front panel are illuminated and the backlight of the LCD is illuminated while the LCD screen is black in color.
5	Gen1 Fault Input	In Cycle start, if the input is active, S1 Gens start will be inhibited.
6	Gen2 Fault Input	In Cycle start, if the input is active, S2 Gens start will be inhibited.
7	Start Inhibit Input	In Auto mode, start signal will deactivated after the stop delay has expired. In Manual mode, if the genset is running, users should stop it manually; then the manual start signal will deactivated.
8	Breaker Trip Input	Trip failure input
9	S1 Close Inhibit	In Manual mode, S1 manual close is inhibited; if breaker already closed, users should open it manually. In Auto mode, if breaker already closed, then close relay will deactivated or S2 take load.
10	S2 Close Inhibit	In Manual mode, S2 manual close is inhibited; if breaker already closed, users should open it manually. In Auto mode, if breaker already closed, then close relay will deactivated or S1 take load.
11	QS1 Breaker PF Input	When the S1 PF input is active, S1 close relay will activated.
12	QS2 Breaker PF Input	When the S2 PF input is active, S2 close relay will activated.
13	Reserved	
14	Reserved	
15	Alarm Reset	Reset the current alarm.
16	Alarm Mute	Silence the audible alarm.
17	NEL Trip Key	Control the NEL off load manually. Self-reset button is recommended.
18	NEL Return Key	Control the NEL on load again manually. Self-reset button is recommended.



No.	Item	Description
19	S1 Master Input	Set S1 master use compulsively.
20	S2 Master Input	Set S2 master use compulsively.
21	Forced Manual Mode	Set the controller in Manual mode compulsively.
22	Forced Auto Mode	Set the controller in Auto mode compulsively.
23	Panel Lock	Panel button operation are inhibited (Except Up, Down, Confirm, Return, Reset and Mute keys)
24	Reserved	
25	Scheduler Inhibit	Schedule Start and Schedule Not Start function are deactivated.
26	Simulate S1 OK	Simulate S1 voltage is normal; the S1 voltage abnormal delay is deactivated.
27	Simulate S2 OK	Simulate S2 voltage is normal; the S2 voltage abnormal delay is deactivated.
28	Simulate S3 OK	Simulate S3 voltage is normal; the S3 voltage abnormal delay is deactivated.
29	QS3 Breaker PF Input	When the S3 PF input is active, S3 close relay will activated.
30	S3 Close Inhibit	S3 load is inhibit
31	Gen3 Fault Input	In Cycle start, if the input is active, S3 Gens start will be inhibited.
32	Reserved	
33	Auto Charge/Rec.	Auto charge/recover when the input active, auto transfer/nonrestore when invalid.
34	S3 Master Input	S3 has the highest priority.
35	Reserved	
36	Reserved	
37	Simulate KEY OOO	Same function with Panel OOO Key. Please use reset key to control ATS to transfer to OOO.
38	Simulate KEY OOI	Same function with Panel OOI Key. Please use reset key to control ATS to transfer to OOI.
39	Simulate KEY IOO	Same function with Panel IOO Key. Please use reset key to control ATS to transfer to IOO.
40	Reserved	
41	Reserved	
42	Reserved	
43	Simulate KEY OIO	Same function with Panel OIO Key. Please use reset key to control ATS to transfer to OIO.
44	Reserved	
45	Remote Control Inhibit	Remote control is invalid when the input is active.



No.	Item	Description
46	Reserved	
47	Reserved	

8.3.2 OUTPUT PORTS FUNCTION

Table 19 – Output Ports Function Description

No.	Items	Description
0	Not Used	Invalid
1	Custom Combined 1	
2	Custom Combined 2	
3	Custom Combined 3	
4	Custom Combined 4	
5	Custom Combined 5	
6	Custom Combined 6	
7	Reserved	
8	Reserved	
9	Reserved	
10	Reserved	
11	Common Alarm	It includes fault alarm and warn alarm.
12	Common Fault Alarm	It includes Transition Fault alarm and Over Current alarm.
13	Common Warn Alarm	It includes “S1 Phase Sequence Wrong” alarm, “S2 Phase Sequence Wrong” alarm, “S3 S2 Phase Sequence Wrong” alarm, “Over Current” and “Forced Open” alarm.
14	Transition Fault	It includes “QS1 Fail to Close” alarm, “QS1 Fail to Open” alarm, “QS2 Fail to Close” alarm, “QS2 Fail to Open” alarm, “QS3 Fail to Close” alarm, “QS3 Fail to Open” alarm.
15	Audible Alarm	Action when common alarm occurs. Can be connected annunciator externally. When “alarm mute” input is active or 60s delay has expired, it can remove the alarm.
16	Reserved	
17	Genset Start Delay	Output when start signal is initiated.
18	Genset Stop Delay	Output when stop signal is initiated.
19	Elevator Control	Output before the load disconnect or switch transfer. Used for control the running elevator stop at the nearest floor until the switch transfer is terminated.
20	Reserved	
21	S3 Available	
22	S3 Unavailable	
23	S1 Available	Output when S1 power is normal.
24	S1 Unavailable	Output when S1 power is abnormal.
25	S2 Available	Output when S2 power is normal.
26	S2 Unavailable	Output when S2 power is abnormal.




No.	Items	Description
27	S1 Over Current	Output when S1 over current occurs.
28	S2 Over Current	Output when S2 over current occurs.
29	S3 Over Current	Output when S3 over current occurs.
30	Auto Mode	Output when the genset is in Auto mode.
31	Manual Mode	Output when the genset is in Manual mode.
32	Genset Start Output	Control the genset to start.
33	Reserved	
34	QS1 Close Control	Control the QS1 switch to close.
35	QS1 Open Control	Control the QS1 switch to open.
36	QS2 Close Control	Control the QS2 switch to close.
37	QS2 Open Control	Control the QS2 switch to open.
38	QS3 Close Control	Control the QS3 switch to close.
39	QS3 Open Control	Control the QS3 switch to open.
40	NEL01 Trip	Control the NEL off load when the output is active; It can control the NEL on load again when the output deactivated.
41	NEL02 Trip	
42	NEL03 Trip	
43	Reserved	
44	QS3 Closed Input	The close status of S3 switch
45	QS1 Closed Input	The close status of S1 switch
46	QS2 Closed Input	The close status of S2 switch
47	S1 Genset Start	When the system type is "S1 Gen S2 Gen", it controls the S1 genset start.
48	S2 Genset Start	When the system type is "S1 Gen S2 Gen", it controls the S2 genset start.
49	S1S2S3 ATS PowerL1	ATS power supply
50	Reserved	
51	Reserved	
52	S1S2S3 ATS PowerN	
53	Remote Control	Control the output via RS485 command.
54	Input 1 Status	Aux. Input status.
55	Input 2 Status	
56	Input 3 Status	
57	Input 4 Status	
58	Input 5 Status	
59	Input 6 Status	
60	Input 7 Status	
61	Input 8 Status	
62	Reserved	
63	Reserved	
64	S1 Blackout	S1 power supply status
65	S1 Over Volt	
66	S1 Under Volt	



No.	Items	Description	
67	S1 Over Freq		
68	S1 Under Freq		
69	S1 Loss Of Phase		
70	S1 Phase Seq Wrong		
71	Reserved	S2 power supply status	
72	Reserved		
73	S2 Blackout		
74	S2 Over Volt		
75	S2 Under Volt		
76	S2 Over Freq		
77	S2 Under Freq		
78	S2 Loss Of Phase		
79	S2 Phase Seq Wrong	Output during the switch transfer process.	
80	Reserved		
81	Reserved		
82	Reserved		
83	Reserved		
84	Switching		
85	Battery Under Volt		Output when battery under voltage alarm occurs.
86	Battery Over Volt		Output when battery over voltage alarm occurs.
87	Gen Inhibit Work		Output during the Schedule Not Run process.
88	Scheduler Gen Start		Output during the Schedule Run process.
89	Reserved		
90	Reserved		
91	Reserved		
92	Reserved		
93	Reserved		
94	Reserved		
95	Reserved		
96	Reserved		
97	Reserved		
98	S3 Blackout	S3 power supply status	
99	S3 Over Volt		
100	S3 Under Volt		
101	S3 Over Freq		
102	S3 Under Freq		
103	S3 Loss of Phase		
104	S3 Phase Seq Wrong		
105	Reserved		
106	Reserved		
107	S3 Genset Start		Control S3 Genset to start. Used for Gen-Gen system and S3 Gens.

8.3.3 CUSTOM COMBINED

Defined combination output is composed by 3 parts, OR condition output SW1, OR condition output SW2, AND condition output SW3.



SW1 or SW2 is **TRUE**, while SW3 is **TRUE**, Defined combination output is active;

SW1 and SW2 are **FALSE**, or SW3 is **FALSE**, Defined combination output is deactivated.

▲NOTE: SW1, SW2, SW3 can be set as any contents except for “defined combination output” in the output setting.

▲NOTE: 3 parts of defined combination output (SW1, SW2, SW3) couldn't include or recursively include themselves.

Example,

Contents of OR condition output SW1: output port 1 is active;

Close when OR condition output SW1 is active /inactive: close when active (disconnect when inactive);

Contents of OR condition output SW2, output port 2 is active;

Close when OR condition output SW2 is active /inactive: close when active (disconnect when inactive);

Contents of AND condition output SW3: output port 3 is active;

Close when AND condition output SW3 is active /inactive: close when active (disconnect when inactive);

When input port 1 active or input port 2 active, if input port 3 is active, Defined combination output is outputting; If input port 3 inactive, Defined combination output is not outputting;

8.4 When input port 1 inactive and input port 2 inactive, whatever input port 3 is active or not, Defined combination output is not outputting.

DEFINITE TIME DELAY AND INVERSE DEFINITE MINIMUM TIME SETTING

Definite Time: overcurrent delay is definite time delay. Different overcurrent value has corresponding delay.

Inverse Definite Minimum Time(IDMT): overcurrent delay decrease with the increase of overcurrent. Different overcurrent value has corresponding delay.

IDMT formula:

$$T = t / ((IA/IT)-1)^2$$

T: Overcurrent delay (second)

t: Timing multiplier ratio

IA: Current max. load current (L1/L2/L3)

IT: Overcurrent setting value

Example:

$$t = 36$$

$$IA = 550A$$

$$IT = 500A$$

Conclusion: T = 3600s(1hour)

SmartGen

9 HISTORICAL RECORDS

On the main screen press  key and select **Historical Records**, and then press  key again, the screen will show the historical records interface.

Each record includes:

- Record date and time
- Record type
- Event log
- S1 power supply status
- S2 power supply status
- S3 power supply status
- S1 3-phase voltage
- S2 3-phase voltage
- S3 3-phase voltage
- S1 frequency
- S2 frequency
- S3 frequency
- Current IA、IB、IC
- Active power
- Power factor

Maximum pieces of historical record are 200. The first record is latest, and users could check every records by dredge up/down. The latest record will cover the oldest one when records amount exceed 200.

Event log type includes: Action Event, Warn Event and Fault Event. All fault event actions are fault alarm while all warn event actions are warn alarm.

Table 20 – Action Events List

No.	Action Events	Description
1	Closing QS1	Record when the QS1 close relay activated.
2	Closing QS2	Record when the QS2 close relay activated.
3	Closing QS3	Record when the QS3 close relay activated.
4	Opening QS1	Record when the QS1 open relay activated.
5	Opening QS2	Record when the QS2 open relay activated.
6	Opening QS3	Record when the QS3 open relay activated.
7	NEL1 Trip	Record when the NEL 1 Trip output.
8	NEL2 Trip	Record when the NEL 2 Trip output.
9	NEL3 Trip	Record when the NEL 3 Trip output.



No.	Action Events	Description
10	Genset Start	Record when the Genset Start signal output.
11	S1 Genset Start	Record when the S1 Genset Start signal output.
12	S2 Genset Start	Record when the S2 Genset Start signal output.
13	S3 Genset Start	Record when the S3 Genset Start signal output.
14	Genset Stop	Record when the Genset Start signal deactivated.
15	S1 Genset Stop	Record when the S1 Genset Start signal deactivated.
16	S2 Genset Stop	Record when the S2 Genset Start signal deactivated.
17	S3 Genset Stop	Record when the S3 Genset Start signal deactivated.
18	Auto Mode	Record when the genset mode transferred to Auto Mode.
19	Manual Mode	Record when the genset mode transferred to Module Mode.
20	Manual Key OOO	
21	Manual Key IOO	
22	Manual Key OIO	
23	Manual Key OOI	
24	Remote Key OOO	
25	Remote Key IOO	
26	Remote Key OIO	
27	Remote Key OOI	

10 BLACK BOX RECORDS

On the main screen press /OK key and select **Black Box Records**, and then press /OK key again, the screen will show the black box records interface.

Each record includes:

- Record date and time
- Record type
- Event log
- S1 power supply status
- S2 power supply status
- S3 power supply status
- S1 3-phase voltage
- S2 3-phase voltage
- S3 3-phase voltage
- S1 frequency
- S2 frequency
- S3 frequency



Current IA、IB、IC

Active power

Power factor

Maximum pieces of black box record are 5. Every event records total 60s (before and after) data information of this event, and record once per second. The latest record will cover the oldest one when records amount exceed 5. The first record is latest. Users could check details by pressing Confirm Key, and could check the 60 datas by dredge up/down.

Event log type: the action event of close/open switching in auto mode.

Table 21 – Action Events List

No.	Action Events	Description
1	Auto Action OOO	Open in auto mode
2	Auto Action IOO	QS1 Close in auto mode
3	Auto Action OIO	QS2 Close in auto mode
4	Auto Action OOI	QS3 Close in auto mode

11 SWITCH OPERATION

11.1 MANUAL OPERATION

Manual mode is selected by pressing the  button; a LED besides the button will illuminate to confirm the operation.

ATS will start to switch immediately after pressing Switch Key. During the switching, corresponding lamps will flash, and then the lamp will be normally illuminated when switch is done. If fail to close or fail to open occurs in the switching process, the controller will alarm (Switch Key is still active and the operation can be redone).

Table 22 – Manual Transfer Keys

Icon	Key Name	Description
	IOO	After pressing this key, if load is off, QS1 will close, otherwise the ATS open firstly then QS1 will close (S1 supply).
	OIO	After pressing this key, if load is off, QS2 will close, otherwise the ATS open firstly then QS2 will close (S2 supply).
	OOI	After pressing this key, if load is off, QS3 will close, otherwise the ATS open firstly then QS3 will close (S3 supply).
	OOO	Load is off after pressing this key.

11.2 AUTOMATIC OPERATION

Auto mode is selected by pressing the  button; a LED besides the button will illuminate to confirm the operation.

Under auto mode, the controller will switch automatically to ensure power supply according to S1 S2 S3 status, switch priority and AutoCharge/Recover status. Examples are showed below:

Table 23 – Auto Breaker Transfer Logic

Power Status	Breaker and Load Status	S1>S2>S3	S2>S1>S3	S3>S1>S2
S1 Normal S2 Normal S3 Normal AutoCharge/Recover	Breaker Status	Status IOO QS1 Close QS2 Open QS3 Open	Status OIO QS2 Close QS1 Open QS3 Open	Status OOI QS3 Close QS1 Open QS2 Open
	Load Status	S1 Supply	S2 Supply	S3 Supply
S1 Normal S2 Abnormal S3 Normal AutoCharge/Recover	Breaker Status	Status IOO QS1 Close QS2 Open QS3 Open	Status IOO QS1 Close QS2 Open QS3 Open	Status OOI QS3 Close QS1 Open QS2 Open
	Load Status	S1 Supply	S1 Supply	S3 Supply
S1 Abnormal S2 Normal S3 Normal AutoCharge/Recover	Breaker Status	Status OIO QS2 Close QS1 Open QS3 Open	Status OIO QS2 Close QS1 Open QS3 Open	Status OOI QS3 Close QS1 Open QS2 Open
	Load Status	S2 Supply	S2 Supply	S3 Supply
S1 Abnormal S2 Abnormal S3 Normal	Breaker Status	Status OOI QS3 Close QS1 Open QS2 Open	Status OOI QS3 Close QS1 Open QS2 Open	Status OOI QS3 Close QS1 Open QS2 Open
	Load Status	S3 Supply	S3 Supply	S3 Supply
S1 Abnormal S2 Abnormal S3 Abnormal (With under volt trip function)	Breaker Status	Status OOO QS1 Open QS2 Open QS3 Open		
	Load Status	Off load		

During the switching process, if fail to close or close inhibit occurs, the corresponding switch will close no more, and other closable switch will supply power. If fail to open occurs, the switch won't execute any order.

12 ATS POWER SUPPLY

Switch Power Type can be set as DC Power or AC Power. If DC Power is selected, then the switch can be transferred at any time (even when both S1 S2 and S3 are outage). If AC Power is selected, whether the power is normal or not should be judged according to the voltage status of S1 S2 and S3 and AC power voltage.

The controller will intelligent control to supply when the power of ATS switch is from S1 and S2. As long as 1 voltage of S1 and S2 is normal, the controller can ensure ATS voltage power normal and can be transferred properly. When ATS voltage power is from LO and NO, it will send close/open signal only if the controller detects voltage power normal.




Fig.2 – Internal Wiring of ATS Power LO-NO Output

The controller will intelligent control to supply when the power of ATS switch is from S1 S2 and S3. As long as 1 voltage of S1 S2 and S3 is normal, the controller can ensure ATS voltage power normal and can be transferred properly. Users need to respectively connect LO, A3 (A phase of S3) to Terminal51 (normally close) and Terminal52 (normally open) of Aux. Output11; and respectively connect NO, N3 (N phase of S3) to Terminal54 (normally close) and Terminal55 (normally open) of Aux. Output12; then connect the COM of Aux. Output11 and 12 to ATS power supply. Then set Aux. Output11 as corresponding phase voltage “S1S2S3ATS PowerL1”, set Aux. Output12 as “S1S2S3ATS Power N” in parameter setting interface. Please refer connection method as below:




Fig.3 –Wring of ATS Supplied by Any of S1S2S3

13 NEL CONTROL

13.1 ILLUSTRATION

Non-essential load ---- NEL for short, which refers to load can be ramped off in prior when genset power is undercapacity.

The controller can control the NEL1, NEL2 and NEL3 to trip separately. The order of the essentiality is: NEL3 > NEL2 > NEL1

13.2 AUTO OPERATION


When NEL auto trip is enabled:

If the genset power has exceeded the NEL trip value, after the trip delay, NEL1 will trip the earliest, and then is NEL2, NEL3;

When NEL auto reconnection is enabled:

If the genset power has fallen below the auto reconnection set value, after the auto reconnection delay, NEL3 will reconnection the earliest, and then is NEL2, NEL1;

t1: NEL Trip Delay
t2: Reconnection Delay



13.3 MANUAL OPERATION

If NEL manual trip input is active (earthed falling edge is active), NEL1 will trip without delay; If NEL manual trip input is active again, NEL2 will trip; If NEL manual trip input is active the third time, NEL3 will trip. During this process, the controller do not detect if the genset power has exceed the NEL trip value or not.

If NEL manual reconnection input is active (earthed falling edge is active), NEL3 will reconnect without delay; If NEL manual reconnection input is active again, NEL2 will reconnect; If NEL manual reconnection input is active the third time, NEL1 will reconnect. During this process, the controller detects the genset power: if the genset power has fallen below the NEL reconnection value, then the

input is active; if it doesn't, the input is deactivated.



Note: When auto trip and auto reconnection are enabled, manual trip is still active.

14 COMMUNICATION CONFIGURATION

HAT833 ATS controller equips with 2 RS485 serial ports which enable the connection of LAN. It uses Modbus protocol via PC or system software, it can also be applicable to dual power switching management to factories, telecom, industrial and civil buildings, which achieves “remote control, remote measuring, remote communication” functions.

More information of Communication Protocol, please refer to “HAT833 Communication Protocol”

Communication parameters:

Module address	1 (range: 1-254)
Baud rate	9600 bps (2400/4800/9600/19200bps)
Data bit	8-bit
Parity bit	None
Stop bit	2 bits (1 bit or 2 bits)

There is a D-type USB port which can be used to connect PC for software upgrading and parameter setting.

SmartGen

15 TERMINALS




Fig.4 – Controller Rear Panel Drawing

Table 24 – Inputs/Outputs Function Description

No.	Items	Description	Remark
1	AUX.OUTPUT1	Relay Output1	Default: QS1 Close Control
2			Volts free; Relay contact; Normally Open output. Capacity: 250V16A
3	AUX.OUTPUT2	Relay Output2	Default: QS1 Open Control
4			Volts free; Relay contact; Normally Open output. Capacity: 250V16A
5	AUX.OUTPUT3	Relay Output3	Default: QS2 Close Control
6			Volts free; Relay contact; Normally Open output. Capacity: 250V16A
7	AUX.OUTPUT4	Relay Output4	Default: QS2 Open Control
8			Volts free; Relay contact; Normally Open output. Capacity: 250V16A
9	AUX.OUTPUT5	Relay Output5	Default: QS3 Close Control
10			Volts free; Relay contact; Normally




No.	Items	Description	Remark
			Open output. Capacity: 250V16A
11	AUX.OUTPUT6	Relay Output6	Default: QS3 Open Control
12			Volts free; Relay contact; Normally Open output. Capacity: 250V16A
13	LO	ATS Power L	Power supply for ATS switching (S1 and S2)
14	NO	ATS Power N	
15	A1	S1 AC System 3P4W voltage input	For single phase, only connect A1, N1
16	B1		
17	C1		
18	N1		
19	A2	S2 AC System 3P4W voltage input	For single phase, only connect A2, N2
20	B2		
21	C2		
22	N2		
23	A3	S3 AC System 3P4W voltage input	For single phase, only connect A3, N3
24	B3		
25	C3		
26	N3		
27	B-	Connect to DC negative pole	Ground terminal
28	B+	Connect to DC positive pole	DC(8-35)V; Power supplied by controller.
29	QS1 CLOSE INPUT	QS1 Close Status Input	Detect QS1 close status, volts free, relay contact. Ground connected is active.
30	QS2 CLOSE INPUT	QS2 Close Status Input	Detect QS2 close status, volts free, relay contact. Ground connected is active.
31	QS3 CLOSE INPUT	QS3 Close Status Input	Detect QS3 close status, volts free, relay contact. Ground connected is active.
32	QS12 CLOSE INPUT	Null	This terminal is not defined.
33	AUX. INPUT 1	Digital Input1	Default: Forced Open Ground connected is active.
34	AUX. INPUT 2	Digital Input2	Default: Breaker Trip Input



No.	Items	Description	Remark
			Ground connected is active.
35	AUX. INPUT 3	Digital Input3	Default: Not Used Ground connected is active.
36	AUX. INPUT 4	Digital Input4	Default: Not Used Ground connected is active.
37	AUX. INPUT 5	Digital Input5	Default: Not Used Ground connected is active.
38	AUX. INPUT 6	Digital Input6	Default: Not Used Ground connected is active.
39	AUX. INPUT 7	Digital Input7	Default: Not Used Ground connected is active.
40	AUX. INPUT 8	Digital Input8	Default: Not Used Ground connected is active.
41	B-(GND)	Ground terminal	Connect to B- internally.
42	AUX. OUTPUT 7	Relay Output7	Default: Not Used
43			Volts free; Relay contact; Normally Open output. Capacity: 250V8A
44	AUX. OUTPUT 8	Relay Output8	Default: Not Used
45			Volts free; Relay contact; Normally Open output. Capacity: 250V8A
46	AUX. OUTPUT 9	Relay Output9	Default: Not Used
47			Volts free; Relay contact; Normally Open output. Capacity: 250V8A
48	AUX. OUTPUT 10	Relay Output10	Default: Not Used
49			Volts free; Relay contact; Normally Open output. Capacity: 250V8A
50	AUX. OUTPUT 11	COM	Relay Output11
51		Normally Close	
52		Normally Open	
53	AUX. OUTPUT 12	COM	Relay Output12
54		Normally Close	
55		Normally Open	



No.	Items	Description	Remark
56	IA In	CT Secondary A-Phase current input	
57	IA Out		
58	IB In	CT Secondary B-Phase current input	
59	IB Out		
60	IC In	CT Secondary C-Phase current input	
61	IC Out		
62	RS485-2 B(-)	RS485-2 communication port	120Ω impedance matched resistance should be connected according to the different situation.
63	RS485-2 A(+)		
64	PE	Ground terminal	
65	RS485-1 B(-)	RS485-1 communication port	120Ω impedance matched resistance should be connected according to the different situation.
66	RS485-1 A(+)		
USB	USB	D-type USB communication port	Parameters setting and software upgrading via PC



16 TYPICAL WIRING DIAGRAM




Fig.5 –Breaker Application Diagram

MCH; Stored Energy Motor; MN: Under Voltage Trip; MX: Open Relay; XF: Close Relay;

Table 25 – Corresponding Settings

Partial Parameters Setting	
Aux. Output 1	QS1 Close
Aux. Output 2	QS1 Open
Aux. Output 3	QS2 Close
Aux. Output 4	QS2 Open
Aux. Output 5	QS3 Close
Aux. Output 6	QS3 Open
Aux. Output 11	Genset Start
Aux. Input 1	Forced Open
Aux. Input 2	Breaker Trip Input




Fig.6 – Contactor Application Diagram

Table 26 – Corresponding Settings

Partial Parameters Setting	
Continually Close	Enabled
Transfer Time	10s (can be set according to actual conditions, mustn't be 0)
Aux. Output 1	QS1 Close
Aux. Output 3	QS2 Close
Aux. Output 5	QS3 Close
Aux. Output 11	Genset Start
Aux. Input 1	Forced Open

Note: The diagrams above are only for example, please do wiring according to actual conditions.

17 INSTALLATION

Controller is panel built-in design; it is fixed by clips when installed. The controller's overall dimensions and cutout dimensions for panel, please refers to as following,




Fig.7 – Overall & Cutout Dimensions




Fig.8 – Clips Installation Drawing

Installation Steps:

1. Install these 4 clips (put into grooves in front panel) in turn.
2. Tighten the screws by using straight screwdriver.
3. Tighten the 4 hex nuts by using M4 sleeve.

Table 27 - Troubleshooting

Symptoms	Possible Solutions
Controller no response with power.	<p>Check DC voltage.</p> <p>Check DC fuse.</p> <p>Check AC Power supply.</p>
RS485 communication is abnormal	<p>Check RS485's connections of A and B is reverse connect or not.</p> <p>Check RS485 transfer model whether damage or not.</p> <p>Check the module address.</p> <p>If above methods can't solve the problem, parallel connection 120Ω resistor between RS485 A terminal and B terminal is recommended.</p>
Auxiliary Output Error	<p>Check auxiliary output connections, pay attention to normally open contact and normally close contact.</p> <p>Check the output settings in parameters settings.</p>
Auxiliary Input Abnormal	<p>Ensure that the auxiliary input is soundly connected to GND when it's active, while hung up when it is inactive.</p> <p>(▲Note: The input port will be possibly destroyed when connected with voltage)</p> <p>Check the input settings in parameters settings.</p>
Genset running while ATS not transfer	<p>Check ATS.</p> <p>Check the connection wirings between the controller and the ATS.</p> <p>Check ATS power and its connection.</p>
Genset Start Abnormal	<p>Check system type setting.</p> <p>Check the output settings in parameters settings.</p> <p>Check all Start/Stop settings.</p>